



12014

Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|-----------|------------------------------------|-----|--------------------------|----------|
| 1 | 1674 | 814247A 1 | GEAR HOUSING, Basic Black | 1 | | |
| 1 | 1674 | 814247A 2 | GEAR HOUSING , Basic Gray | 1 | | |
| 44 | | 76039 | CAM, Shift Control | 1 | | |
| 45 | | 12239A 1 | FOLLOWER KIT, Cam | 1 | | |
| 46 | 24 | 30622 | SPRING | 1 | | |
| 47 | 15 | 44491A 1 | SHIM SET | AR | | |
| 48 | 31 | 30894A 1 | BEARING SET, Cup And Cone | 1 | | |
| 49 | 43 | 16279A 2 | FORWARD GEAR | 1 | | |
| 50 | 31 | 30895 | BEARING, Needle | 1 | | |
| 51 | 52 | 822539 | CLUTCH | 1 | | |
| 52 | 17 | 30632 | PIN, Cross | 1 | | |
| 53 | 24 | 30893 | SPRING | 1 | | |
| 54 | 44 | 12238T | PROPSHAFT | 1 | | |
| 55 | | N.S.S. | Not Sold Seperate, Reverse Gear (I | 1 | | |
| 56 | 12 | 76358 | THRUST WASHER | 1 | | |
| 57 | 25 | 29976 | O-RING | 1 | | 2,15 |
| 58 | | 41529A 2 | BEARING CARRIER ASSEMBLY | 1 | | |
| 59 | 22 | 98727 | FITTING, Grease | 2 | | |
| 60 | 31 | 30956 | BEARING, Needle | 1 | | |
| 61 | 26 | 76868 | SEAL | 2 | | 15 |
| 62 | 28 | 30281 | KEY | 1 | | |
| 63 | 14 | 52700 | TAB WASHER | 1 | | |
| 64 | | 52699 | COVER | 1 | | |
| 65 | | 67891 | FILLER BLOCK | 1 | | |
| 66 | 10 | 65210 | SCREW, (.375-16 x 1.00) | 1 | THESE REPLACEMENT PARTS. | |
| 68 | 14 | 816629 | TAB WASHER | 1 | THESE REPLACEMENT PARTS. | |
| 69 | 11 | 52707A 1 | NUT KIT, Propeller | 1 | THESE REPLACEMENT PARTS. | |
| 70 | | 31640 4 | TRIM TAB | 1 | THESE REPLACEMENT PARTS. | |
| 71 | 10 | 806327 | SCREW, (.437-14 x 1.750) | 1 | THESE REPLACEMENT PARTS. | |
| 72 | 12 | 45176 | WASHER, (.453 x .812 x .105) | 2 | THESE REPLACEMENT PARTS. | |
| 73 | 11 | 34933 | NUT, (.437-20) | 2 | THESE REPLACEMENT PARTS. | |
| 74 | | 13191A 1 | HUB, Thrust | 1 | THESE REPLACEMENT PARTS. | |
| - | 27 | 815791A92 | ENGINE GASKET SET | 1 | THESE REPLACEMENT PARTS. | |
| - | 26 | 89238A 2 | SEAL KIT | 1 | THESE REPLACEMENT PARTS. | |