



12018

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
0	1647	9148A18	GEAR HOUSING	1	(LONG)(BLACK)	
0	1647	9148A19	GEAR HOUSING	1	(X-LONG)(BLACK)	
0	1647	9148A20	GEAR HOUSING	1	(LONG)(GRAY)	
0	1647	9148A21	GEAR HOUSING	1	(X-LONG)(GRAY)	
1	1647	9148A11	GEAR HOUSING ASSEMBLY	1	(BASIC) (BLACK)	
1	1647	9148A12	GEAR HOUSING ASSEMBLY	1	(BASIC)(GRAY)	
48		78956	SHIFT CAM	1		
49		89594A 1	FOLLOWER	1		
50		816520	ROD	1		
51	24	79910	SPRING	2		
52	12	78910	WASHER	AR		
53	17	78906	PIN	1		
54	15	47397A 1	SHIM SET	AR		
55	31	78172A 1	BEARING ASSEMBLY, Tapered	1		
56	43	44102A 2	FORWARD GEAR ASSEMBLY	1		
57	31	73363	ROLLER BEARING	2	(5/8")	
57	31	54928 1	ROLLER BEARING	1	(1")	
58	52	78959	RATCHET	1		
59	17	78905	PIN, Cross	1		
60	17	78909	PIN, Detent	2		
61	24	78962	SPRING	2		
62	44	94148	PROPELLER SHAFT	1		
63		NSS	NOT SOLD SEPARATE, Reverse	1		
63A	23	824108	SPACER	1		
64		68100 1	RING, Thrust	1		
65	30	88957A 1	BEARING	1		
66	25	31534	O-RING	1		4,14
67		43567A 1	BEARING CARRIER ASSEMBLY	1		
68	31	30956	BEARING, Needle	1		
69	26	76868	SEAL	2		14
70	28	30281	KEY	1		
71	14	79447	TAB WASHER	1		
72		79448	RETAINER	1		
73		31640A 1	TRIM TAB ASSEMBLY	1		
74	10	66024	SCREW, (.437-14 x 1.75)	1		
75		67891	FILLER BLOCK	1		
76	11	34933	NUT, (.437-20)	2		
77	10	65210	SCREW, (.375-16 x 1.00)	1		
77	10	74727	SCREW, (.375-16 x 6.00)	1		
78		13171	THRUST HUB	1		
79	12	21211A 2	WASHER, Self-c	1		