



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	27	19050 6	GASKET	1		2,5
2		828343A 4	DIVIDER PLATE	1		5
3	26	814754	SEAL	1		2,5
4	10	826356 1	SCREW (5/16-18 X 1-1/2 IN.)	17		5
5	10	881190	SCREW (5/16-18 X 1 IN.)	2		5
6		68729 1	COVER-RELIEF VALVE	1		5
7	10	74824	SCREW (5/16-18 X 1-1/4 IN.)	4		5
8	10	69570	SCREW (10-16 X 3/4 IN.)	1		5
9	12	76451	WASHER	1		5
10		14479 1	DIAPHRAGM	1		5
11		16496	WATER DEFLECTOR	1		5
12		16497A 1	PLATE	1		5
13	27	78690	GASKET	2		2,5
14	24	42996	SPRING	1		5
15		14480	POPPET	1		5
16	25	64872	GROMMET	1		5
17		65848	CARRIER	1		5
18	27	99176 4	GASKET	1		2
19		850814T 2	EXHAUST PLATE	1	(S/N-0T598999 & BELOW)	
19		850814T 4	EXHAUST PLATE	1	(S/N-0T599000 & UP)	1
20	17	43044	DOWEL PIN	2		
21		814701 1	SEAL	1		
22		68010 1	BRACKET	1		
23	10	878608	SCREW (10-16 X 1/2 IN.)	8		
24	25	19565	GROMMET	1		
25	12	20553	WASHER	4		
26	11	69254	NUT	6		
27	23	27132	BUSHING	1		
28	10	66727	SCREW (5/16-18 X 1-1/4 IN.)	1		
29	10	68783	SCREW (5/16-18 X 2-1/2 IN.)	1		
30	10	66725	SCREW (3/8-16 X 3-1/2 IN.)	3		
31		812905A 5	FRONT BRACKET ASSEMBLY	1		
32	10	805557 1	SCREW (5/16-18 X 1/2 IN.)	4		
33	12	18703 1	WASHER	4		
34	25	18778T	GROMMET	4		
35		18578T 8	REAR BRACKET ASSEMBLY	1		
36	25	12602 1	GROMMET	1		
37	10	35385	SCREW (.312-18 X 1-3/4 IN.) (SLA)	1		
-	27	814754A00	ENGINE GASKET SET	1		
-		879808T01	POWERHEAD	1	(135/150)	
-		879809T01	POWERHEAD	1	(175)	