



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		826729A	POWER TRIM ASSEMBLY-COMPI	1		5
1		811604F	MANIFOLD ASSEMBLY	1		
2	22	56800	PIPE PLUG	9		
3		823552F	TILT CYLINDER ASSEMBLY	1		
4		823553	PISTON ROD	1		
5		811606	GUIDE KIT	1		
6		811607A	REPAIR KIT	1		
7		811610A	CHECK VALVE KIT	1		
8		99638A	GUIDE ASSEMBLY	2		
9		43397A	PISTON/ROD ASSEMBLY	1	(PORT)	
9		43398A	PISTON/ROD ASSEMBLY	1	(STBD.)	
10	35	12184A	TRIM FILTER ASSEMBLY	1		
11		813442A	VALVE ASSEMBLY	1		
12	53	812844	E RING	1		
13		811612A	O RING KIT	1		
14		811617F	PUMP	1		
15	19	811613	PLUG ASSEMBLY	1		
16	10	40003	SCREW	4		
17	12	43450	WASHER	4		
18		811611	COVER	1		
19		828710	DRIVE SHAFT	1		
20		828708	TRIM MOTOR (BREAKDOWN O	1		
21	10	828709	SCREW	2	(LONG)	
21	10	811616	SCREW	2	(SHORT)	
22		811614	SHAFT ASSEMBLY	1		
23	22	56800	PIPE PLUG	2		
24	17	44431	GROOVE PIN	1		
25	17	821539	GROOVE PIN	1		
26		99625	SHAFT	1		
27		818298A	ANODE ASSEMBLY	1		
28	10	40003	SCREW (M6 X 1 X 25)	2		
29	12	29245	WASHER	2		
30	10	40003	SCREW (M10 X 1.5 X 30)	6		
31	12	40023	WASHER	6		
32	54	26550	CLIP	2		
33	10	817626	SCREW (10-16 X .44)	2		
34		69205	C WASHER	2		
35		99630	STRIKER PLATE	2		
36	13	58643	LOCKWASHER	2		
37	11	46335	NUT	2		