



9 Loctite PST Pipe Sealant (92-809822)
 14 2 Cycle Outboard Oil (92-82666A24)

A = To Tell-Tale Hose
 B = To Adaptor Plate

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		858281T 2	CYLINDER HEAD	2	(150)	5
1		858281T 1	CYLINDER HEAD	2	(175/200)	5
2		858452 1	SEAL	2		5
3		859772 1	SEAL	6		5
4	10	832971	SCREW	23		
4	10	827426 1	SCREW	1		
5	17	63779	DOWEL PIN	4		5
6	27	62386	GASKET	2		5,2
7		90390A 1	COVER	2		5
8		75692	THERMOSTAT	2		5
9	10	40011149	SCREW (M8 X 25)	4		5
10	22	68727 1	ELBOW	1		5
11	32	77653101	HOSE (12-3/4 IN.)	1		5
12	22	68728	FITTING	1		5
13	54	816311T	STA-STRAP	AR		
14	32	77653101	HOSE (13-1/2 IN.)	1		5
15	32	77653101	HOSE (4-1/2 IN.)	1		
16		97465 1	TEMPERATURE SENDER (STBD.)	1		5
17	22	815914	T-FITTING	1		
18		13536A14	TEMPERATURE SENSOR (PORT)	1		
19		13715 1	RETAINER	2		5
20	10	818934 14	SCREW (M8 X 14)	2		5
21		826858	KNOCK SENSOR (200)	1		
22	11	45076	NUT	1		
23		17735A 2	ADAPTOR PLATE	1		
24	10	28668	SCREW (1/4-20 X 7/8)	8		
25	27	14697 2	GASKET	1		2
26		855952T 3	REED BLOCK	6		
27	54	55098	J-CLAMP	1		
28	10	55715	SCREW (1/4-20 X 7/8 IN.)	6		
29	10	90197	SCREW (1/4-20 X 1-1/8 IN.)	6		
30	27	16737 1	GASKET	1		2
31	54	65292	J-CLIP	1		
32	10	878608	SCREW (10-16 X 1/2)	1		
33		69205	C WASHER	1		
-	27	815791A00	ENGINE GASKET SET	1		
-		823434T00	POWERHEAD	1	(150)	
-		823434T00	POWERHEAD	1	(150)	
-		812817T00	POWERHEAD	1	(175)	
-		813043T00	POWERHEAD	1	(200)	