



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		18896A	FLYWHEEL COVER ASSEMBLY	1		
2		79022	MARKER	1		
3	10	37572	SCREW (3/16-32 X 3/8)	2		
4	12	72761	WASHER	2		
5	19	89219	PLUG (USE WHERE APPLICABLE)	1		
6	19	45907	PLUG	1		
7	11	52901	NUT	1		
8	12	68229	WASHER	1		
9	271	817632A12	FLYWHEEL	1		
10	398	9610A19	STATOR	1		
11	10	90045	SCREW (10-32 X 1-3/8)	4		
12	13	26996	WASHER	4		
13		96455A 9	TRIGGER PLATE ASSEMBLY	1		
14	50	79472	STARTER MOTOR	1		
15		56703	COLLAR	2		
16		68042	RUBBER STOP	2		
17	10	69035	SCREW (1/4-20 X 5/8)	1		
18	84	93388A 1	WIRE ASSEMBLY (BLACK)	1		
19	84	93388A 7	WIRE ASSEMBLY (BLACK)	1		
20	13	26992	LOCKWASHER	1		
21	11	20890	NUT	1		