



| Parts List | | | | | | |
|------------|-------|----------|------------------------------|-----|------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 1647 | 9148A47 | GEAR HOUSING | 1 | (BASIC-BLACK) | |
| 1 | 1647 | 9148A48 | GEAR HOUSING | 1 | (BASIC-GRAY) | |
| 51 | | 89594A 1 | CAM FOLLOWER | 1 | | |
| 52 | | 78956 2 | SHIFT CAM | 1 | | 5 |
| 53 | | 79911 1 | ROD | 1 | | |
| 54 | 17 | 78906 | PIN | 1 | | |
| 55 | 24 | 79910 | SPRING | 2 | | |
| 56 | 12 | 78910 | WASHER | AR | | 8 |
| 57 | | 14469 | BEARING CUP | 1 | | |
| 58 | 30 | 88957 | BALL BEARING | 1 | | 5 |
| 59 | | NSS | REVERSE GEAR (PART OF 43-18) | 1 | (1.87:1 - 15/28) | 6 |
| 60 | 31 | 15844 | ROLLER BEARING | 1 | | |
| 61 | 52 | 823174 | CLUTCH | 1 | | |
| 62 | 17 | 78909 | DETENT PIN | 2 | | |
| 63 | 17 | 78905 | CROSS PIN | 1 | | |
| 64 | 24 | 78962 | SPRING | 2 | | |
| 65 | 43 | 18475A 1 | FORWARD GEAR | 1 | (1.87:1 - 15/28) | |
| 66 | 23 | 17615 1 | SPACER SHIM .125 IN. | AR | | 8 |
| 66 | 23 | 17615 2 | SPACER SHIM .127 IN. | AR | | 8 |
| 66 | 23 | 17615 3 | SPACER SHIM .129 IN. | AR | | 8 |
| 66 | 23 | 17615 4 | SPACER SHIM .131 IN. | AR | | 8 |
| 66 | 23 | 17615 5 | SPACER SHIM .133 IN. | AR | | 8 |
| 66 | 23 | 17615 6 | SPACER SHIM .135 IN. | AR | | 8 |
| 66 | 23 | 17615 7 | SPACER SHIM .137 IN. | AR | | 8 |
| 66 | 23 | 17615 8 | SPACER SHIM .139 IN. | AR | | 8 |
| 66 | 23 | 17615 9 | SPACER SHIM .141 IN. | AR | | 8 |
| 66 | 23 | 17615 10 | SPACER SHIM .143 IN. | AR | | 8 |
| 66 | 23 | 17615 11 | SPACER SHIM .145 IN. | AR | | 8 |
| 66 | 23 | 17615 12 | SPACER SHIM .147 IN. | AR | | 8 |
| 66 | 23 | 17615 13 | SPACER SHIM .149 IN. | AR | | 8 |