



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		875285T 1	ALTERNATOR	1		
2	10	40108100	SCREW (M10 x 100)	1		
3	10	40108120	SCREW (M10 x 120)	1		
4	12	29395	WASHER	3		
5	23	856975	MOUNT	3		
6		858391T	BRACKET	1		
7	12	845998	WASHER	3		
8		858393T	BRACKET	1		
9	11	826292	NUT	2		
10	10	824461 55	SCREW (M10 x 55)	1		
11	84	856583T 2	CABLE	1		
12	12	40023 19	WASHER	1		
13		857142T	BRACKET	1		
14	10	812618	SCREW (5/16-18 x 1 IN.)	3		
15	24	855798	SPRING	1		
16		856815T 2	BELT TENSIONER ARM ASSY	1		
17	16	856900	STUD (M10 x 85)	1		
18	11	826292	NUT	1		
19	23	856894 1	BUSHING	1		
20	12	40023 20	WASHER	2		
21		883471T	PULLEY	1		
22	10	40108 35	SCREW (M10 X 35)	1		
23	57	828507 11	BELT	1		
24	281	859734T 1	FLYWHEEL	1	(USE WITH SOLENOID DRIVEN	
24	281	859734T 4	FLYWHEEL	1	(USE WITH CENTRIFUGAL BENI	
25	11	52901	NUT	1		
26	12	68229	WASHER	1		
27	19	45907	PLUG	1		
28	11	40138 6	NUT	1		