



19563

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		18896A 1	COVER KIT, FLYWHEEL	1		
2		79918A 1	COVER KIT (NON-LOUVERED)	1		
3	10	37572	SCREW, (.190-32 x .380), TIMING	2		
4	12	72761	WASHER, TIMING MARKER SC	2		
5		79022	MARKER, TIMING	1		
6	19	45907	PLUG, (Yellow), FLYWHEEL	1		
7	11	52901	NUT, (.625-18), FLYWHEEL	1		
8	12	68229	WASHER, FLYWHEEL	1		
9	266	9841A 7	FLYWHEEL (USE WITH REF. NO.	1	(WITH SCREWS)	
9	257	7555A17	FLYWHEEL (USE WITH REF. NO.	1	(WITH SCREWS)	
10	10	32417	SCREW, (.250-28 x .625), FLYW	8	(WITH SCREWS)	
11	10	68997	SCREW, (.3125-24 X .75), FLYW	8	(WITH SCREWS)	
12	398	9610A 5	STATOR (40 AMP)	1	(USE WITH REF. NO. 1)	
12	398	5454A35	STATOR (16 AMP)	1	(USE WITH REF. NO. 2 & 9)	
12	398	9873A 4	STATOR (16 AMP - SEE NOTE)	1	(USE WITH REF. NO. 2 & 25)(39E	
13	10	90045	SCREW, (#10-32 x 1.375), STATC	4	(USE WITH REF. NO. 1)	
13	10	99452	SCREW, STATOR	4	(USE WITH REF. NO. 2 & 9)	
13	10	817044	SCREW	4	(USE WITH REF. NO. 2 & 25)	
14	13	26996	LOCKWASHER, (#10), STATOR S	4	(USE WITH REF. NO. 1)	
14	13	26996	LOCKWASHER, (#10)	4	(USE WITH REF. NO. 2 & 25)	
15		96455A 9	TRIGGER PLATE ASSEMBLY	1		
16	84	93388A 1	CABLE ASSEMBLY, Black	1		
17	50	79472	STARTER MOTOR	1		
18		56703	COLLAR, STARTER MOTOR	2		
19		68042	STOP, RUBBER - STARTER MOT	2		
20	13	26992	LOCKWASHER, (.250), STARTER	1		
21	11	20890	NUT, (.250-20), STARTER MOTO	1		
22	84	93388A 2	WIRE, (Black)	1		
23	10	69035	SCREW AND LOCKWASHER, (.25	1		
24	19	89219	PLUG	1		
25	271	817632A 2	FLYWHEEL (USE WITH REF. NO.	1	(WITHOUT SCREWS)	
25	271	817632A 9	FLYWHEEL (USE WITH REF. NO.	1	(WITHOUT SCREWS)	