



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	2197	9744A 2	BOTTOM COWL ASSEMBLY (PDF)	1	1
1	2197	9744A 3	BOTTOM COWL ASSEMBLY (PDF)	1	1
2	2197	9745A 1	BOTTOM COWL ASSEMBLY (STA)	1	1
2	2197	9745A 2	BOTTOM COWL ASSEMBLY (STA)	1	1
3		18701A 1	SEAL KIT, BOTTOM COWLS	1	
4	10	18699	SCREW, COWL (STARBOARD)	4	
5		18872A 1	COVER ASSEMBLY (BLACK)	1	
5		18872A 2	COVER ASSEMBLY (GRAY)	1	
6	11	813692	LOCK NUT	2	
7	54	90077	STA-STRAP	AR	6
8		18727	ROD	1	
9	23	65830	BUSHING, NYLINER	6	
10	23	19666	BUSHING	1	
11	13	99611	WAVE WASHER	3	
12	12	69057	WASHER	3	
13	10	18192	SCREW	1	
14		19648A 3	HANDLE ASSEMBLY (PORT) (BLA	1	
14		19648A 4	HANDLE ASSEMBLY (PORT) (GR	1	
15		19647A 3	HANDLE ASSEMBLY (STARBOAF	1	
15		19647A 4	HANDLE ASSEMBLY (STARBOAF	1	
16		19370	PAWL (PORT)	1	7.8
17		19369	PAWL (STARBOARD)	1	7.8
18	10	90047	SCREW	2	
19	54	19749	CLAMP, UPPER	1	
20	54	19748	CLAMP, LOWER	1	
21	10	92799	SCREW	2	
22	84	16636A 1	HARNES ASSEMBLY, TRIM	1	
23	10	72202	SCREW	2	
24	12	56681	WASHER	2	
25	11	29488	NUT	2	
26	84	16639A 1	TRIM HARNES ASSEMBLY	1	
27	88	79091	FUSE	1	
28	84	95084A 2	WIRE, FUSE	1	
29	22	813613	FITTING, TELLTALE	1	
30	22	90824	TEE, TELLTALE	1	
31	32	99127109	HOSE, TELLTALE	1	
32		813076	FRONT HANDLE ASSEMBLY	1	
33		813925	HANDLE LOCK	1	
34		813926	HANDLE	1	
35	24	813929	SPRING	1	
36	10	69079	SCREW	2	