



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1647	9148A 8	GEAR HOUSING (LONG) (BLACK)	1	
-	1647	9148A 9	GEAR HOUSING (X-LONG) (BLAC)	1	
-	1647	9148A10	GEAR HOUSING (LONG) (GRAY)	1	
-	1647	9148A13	GEAR HOUSING (X-LONG) (GRAY)	1	
1	1647	9148A11	GEAR HOUSING ASSEMBLY (B	1	
1	1647	9148A12	GEAR HOUSING ASSEMBLY (B	1	
48		78956	SHIFT CAM	1	
49		89594A 1	FOLLOWER, CAM	1	
50		79911	ROD, CLUTCH ACTUATOR	1	
51	24	79910	SPRING, COMPRESSION	2	
52	12	78910	WASHER, COOMPRESSION SP	1	6
53	17	78906	PIN, SPRING LOCATOR	1	
54	15	47397A 1	SHIM, BEARING OUTER RACE	AR	6
55	31	78172A 1	TAPERED ROLLER BEARING A	1	
56	43	44104A 2	FORWARD GEAR ASSEMBLY	1	
57	31	73363	ROLLER BEARING, FORWAR	2	
57	31	43999	ROLLER BEARING, FORWAR	2	
58	52	78959	RATCHET, SLIDING CLUTCH	1	
59	17	78905	CROSS PIN, RATCHET TO PRO	1	
60	17	78909	DETENT PIN, RATCHET	2	
61	24	78962	SPRING, RETAINING - CROSS	2	
62	44	94148	PROPELLER SHAFT	1	
63		N.S.S.	REVERSE GEAR (PART OF 43-	1	
64		68100	RING, THRUST	1	BEARING CARRIER TO GEAR H
65	30	88957A 1	BEARING, BALL - REVERSE GE	1	
66	25	31534	"O" RING, BEARING CARRIER	1	2,11
67		43567A 1	BEARING CARRIER ASSEMBLY	1	
68	31	30956	ROLLER BEARING, BEARING	1	
69	26	76868	OIL SEAL, BEARING CARRIEF	2	11
70	28	30281	KEY, LOCATING, BEARING CAF	1	
71	14	79447	TAB WASHER, GEAR HOUSING	1	
72		79448	COVER, GEAR HOUSING	1	
73		31640A 1	TRIM TAB, GEAR HOUSING	1	
74	10	66024	SCREW, TRIM TAB TO GEAR H	1	
75		67891	FILLER BLOCK	1	
76	11	34933	NUT, DRIVE SHAFT HOUSING S	2	
77	10	65210	SCREW, GEAR HOUSING (LONG)	1	
77	10	74727	SCREW, GEAR HOUSING (X-LON	1	
78		13171	THRUST HUB	1	
79	12	31211A 2	WASHER, SPLINED - PROPELLE	1	
80	14	21210	TAB WASHER, PROPELLER NUT	1	