



1894A

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1494	7476T 1	TRANSOM BRACKET	1	(PORT-BLACK)	
2	1495	7478T 1	TRANSOM BRACKET	1	(STBD. - BLACK)	
1	1494	7476T 6	TRANSOM BRACKET	1	(PORT-GRAY)	
2	1495	7478T 6	TRANSOM BRACKET	1	(STBD. - GRAY)	
3	10	67755 2	SCREW, (.500-20 x 6.500)	2		
4	10	67755 1	SCREW, (.500-20 x 4.500)	2		
5	12	28421	WASHER	4		
6	11	35000	NUT, (.500-20)	4		
7	10	87180	BOLT, (.500-20 x 11.00)	1		
8	11	35000	NUT, (.500-20)	1		
9		99170A 1	TILT TUBE	1		
10	13	88750	WAVE WASHER	2		
11	11	56041	NUT, (.875-14)	1		
11	11	90068T	NUT	1	(1"-14 -BLACK)	
11	11	90068T 6	NUT	1	(1"-14 -GRAY)	
12	25	48462	O-RING, (.614 x .070)	1		3
13		85026T	PLATE	2		
14	10	28636	SCREW, (.250-20 x .750)	4		
15	12	29245	WASHER, (.281 x .500 x .060)	1		
16		85035T	SPACER	1		
17	10	70732	SCREW, (.250-20 x 2.00)	4		
18	12	29245	WASHER, (.281 x .500 x .060)	4		
19		89949A 1	PLATE ASSEMBLY	1		
20	10	89996	SCREW, (.250-20 x .875)	4		
21	54	88512	CLAMP	4		
22	10	88829	SCREW, (#10-24 x .500)	4		
23	13	26996	LOCKWASHER, (#10)	4		
24		79610A 6	TRIM CYLINDER ASSEMBLY	1		
		79879A 1	REPAIR KIT	1		
25	23	86489	BUSHING	2		
26	12	85022	WASHER	2		
27	24	30316	SPRING	2		
28	17	85020	PIVOT PIN	2		
29		85024	SHAFT	1		
30	23	86637	BEARING	2		
31	17	91862	PIN	1		
32	32	89024A 1	HOSE	1	(PORT)	
32	32	89023A 2	HOSE	1	(STARBOARD)	
33	25	12602	GROMMET	2		
34	22	87207	CONNECTOR	1		
35		87271	COVER	1		