



18972

					Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote		
1		99659A21	MANIFOLD ASSEMBLY	1	(BLACK)			
1		99659A22	MANIFOLD ASSEMBLY	1	(GRAY)			
2	22	99616	PIPE PLUG, MANIFOLD	11				
3		41493A 7	TRIM CYLINDER ASSEMBLY	1	(BLACK)			
3		41493A 4	TRIM CYLINDER ASSEMBLY	1	(GRAY)			
4		41492A 1	GUIDE ASSEMBLY	1				
5	25	41478A 1	REPAIR KIT	1				
6		41482A 2	CHECK VALVE KIT	1				
7		99638A 1	GUIDE ASSEMBLY, TRIM ROD	2				
8		43397A 6	PISTON AND ROD ASSEMBLY, P	1				
9	35	12184A 1	TRIM FILTER ASSEMBLY	1				
10		43398A 3	PISTON AND ROD ASSEMBLY, S	1				
11	17	13794	PIN, Groove, TRIM CYLINDER (UF	1				
12		812843A 1	VALVE ASSEMBLY	1				
12A	53	812844	E RING	1				
13	10	40003 27	SCREW, (M6 x 14), COVER	4				
14	12	43450	WASHER, COVER SCREW	4				
15		99642	COVER, MANIFOLD	1				
16	25	48462A 2	O-RING KIT	1				
17	19	99609A 1	PLUG ASSEMBLY	1				
18		99641A 1	SHAFT ASSEMBLY	1				
19	22	99616	PIPE PLUG, SHAFT	2				
20	10	40088 20	SCREW, (M6 x 20), PUMP AND MI	2				
21	13	40025 6	LOCKWASHER, (M6)	2				
22		99186 1	POWER TRIM PUMP	1				
23		99625	SHAFT, UPPER	1				
24		43396A 2	ANODE ASSEMBLY	1				
25	10	40003 30	SCREW, (M6 x 25), ANODE	2				
26	12	29245	WASHER, (.281 x .500 x .060), AN	2				
27		99630 1	STRIKER PLATE, TRIM SHAFT	2				
28	13	58643	LOCKWASHER, (.375)	2				
29	11	46335	NUT, (.375-24)	2				
30	84	99695A 1	CONTROL HARNESS ASSEMBLY	1	(3 WIRE)			
30	84	17201A 2	CONTROL HARNESS, (17.00 Inch	1	(2 WIRE)			
31	84	79138A12	WIRE ASSEMBLY	1	(13-1/4" - BLACK)			
31	84	88807A 8	WIRE ASSEMBLY, (Black- 3.5 Incl	2				
31	84	87379A25	WIRE ASSEMBLY, (4.750 Inches)	1				
32	89	96158	SOLENOID STARTER	2				
33	10	28635	SCREW, (.250-20 x .620)	5				
34	11	26419	NUT, (#8-32)	4				
35	12	26992	LOCKWASHER, (.250)	4				