



22350

				Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote	
1		12430A 4	SENSOR ASSEMBLY	1			
2	10	48409	SCREW, (#10-16 x .625), SENSO	1			
3		815698	OIL PUMP (175)	1			
3		815699	PUMP ASSEMBLY, Oil (200)	1			
4	25	11379	O-RING, OIL PUMP	1			
5	23	41429A 2	BEARING ASSEMBLY, DRIVE GE	1			
6	43	14563	GEAR, Driven	1			
7	10	32228	SCREW, (#10-32 x .625), OIL PUM	1			
7	10	41507	SCREW, (#10-32 x 1.120), OIL PUI	1			
8		19385 12	LINK ASSEMBLY, THROTTLE LE	1			
9	32	43016 25	TUBING, (8.00 Inch), OIL PUMP	1			
10		99443T	OIL RESERVOIR	1			
11	54	41582 3	CLAMP, OIL HOSE	2			
12	32	43017 36	TUBING, OIL RESERVOIR TO OIL	1			
13	10	69020	SCREW, (#10-32 x .875), OIL RES	3			
14	12	42118	WASHER, OIL RESERVOIR SCRE	6			
15	25	42117	GROMMET, OIL RESERVOIR SCF	3			
16	23	42116	BUSHING, OIL RESERVOIR SCRE	3			
17	32	99127109	FUEL LINE, (57.00 Inches Bulk)	1			
18	22	42425	TEE, OIL TUBING	1			
19	32	90729 25	HOSE, OIL (6-3/4")	1			
20	54	816311	CABLE TIE, (8.00 Inches)	AP			
21	32	99439	HOSE, (114.00 Inches), OIL	1			
22	54	41582 4	CLAMP	2			
24	21	43278	FITTING, CHECK VALVE (CRANK)	1			
25	1257	8742 1	TANK	1			
26	36	43298A 2	CAP ASSEMBLY, OIL TANK	1			
27	25	11332	O-RING, (2.225 x .210), CAP	1			
28		816190A 3	HOUSING ASSEMBLY, Adapter	1			
29	25	11332	O-RING, (2.225 x .210), ADAPTO	1			
30	32	99802	TUBE, OIL PICK-UP	1			
31	36	43300A 9	CAP ASSEMBLY, OIL RESERVOIR	1			
32	27	43307	GASKET, RESERVOIR CAP	1			
33		99022A 1	FLOAT ASSEMBLY	1			
34	11	99265	PUSHNUT	1			