



12002

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	884	9763A23	CYLINDER BLOCK (150)	1		3
1	884	9763A17	CYLINDER BLOCK (175)	1		3
1	884	9763A61	CYLINDER BLOCK (200)	1		3
2	16	76175	STUD, Powerhead (1.875) (Old D	4		
2	16	818138	STUD, Powerhead (1.75")	2 OR 6		3
3	16	67065	STUD, Powerhead (5.50")	2		3
3	16	78438	STUD, Powerhead (6.75")	2		3
4	17	43044	PIN, Dowel (.375 x .625) (Witho	2		3
5	17	67296	PIN, Bearing Race	2		3
6	27	11338	GASKET, Sealing	2		2,3
7		42249	COVER, Starter Motor-Upper	1		3
8	10	828213	SCREW, (.312-18 x 1.500), Hex F	2		3
8	10	73657	SCREW, (.312-18 x 1.50), Use Tr	2		3
9	13	26993	LOCKWASHER, (.312)	4		3
10		76867	COVER, Lower	1		3
11	10	815549	SCREW, .312-18 x 2.00	2		3
11	10	828214	SCREW, (.312-18 x 2.00), Hex H	2		3
12	23	99448	BUSHING	1		3
13	84	88807A20	CABLE ASSEMBLY	1		
14	10	66717	SCREW, (.375-16 x 3.250)	8		3
14	10	74824	SCREW, (.312-18 x 1.250)	6		3
-		823434A93	POWERHEAD (150)	1		
-		821861A92	POWERHEAD (175)	1		
-		813043A94	POWERHEAD (200)	1		
15	1159	9642A 1	END CAP ASSEMBLY, Upper	1		3
16	25	54029	O-RING, (2.800 x .103)	1		3
17	31	16756A 4	BEARING KIT	1		3
18	26	41953	SEAL	1		3
19	10	69034	SCREW AND LOCKWASHER, (.31	4		3
20	54	63153	J CLIP	1		
21	16	15094	STUD, (.190-32 x 1.870)	1		
22	23	67269	SPACER	1		
23	12	49221	WASHER	6		
24	11	816874	WING NUT, (#10-32)	3		
25	54	16793	CLAMP	1		
26	10	41508	SCREW, (.250-20 x .500)	1		
27	16	15093	STUD, (#10-32 x 1.00)	2		
28		42248	BRACKET	1		3
29	10	49668	SCREW, (.250-20 x .750)	2		3
30	1156	7809A 1	END CAP ASSEMBLY	1		3
31	25	62200	O-RING, (3.227 x .103)	1		2,2