



19565

					Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote	
1		43429	IGNITION PLATE	1			
2	332	7778A	SWITCH BOX	2			
3	10	13669	SCREW, (12-24 x 2.00), SWITCH	2			
4	23	94453	BUSHING, SWITCH BOX SCREW	2			
5	84	62310A	CABLE ASSEMBLY, SWITCH BOX	1			
6	11	45076	NUT, (#10-32), SWITCH BOX TER	20			
7	84	60871A10	WIRE ASSEMBLY, SWITCH BOX	2			
8	10	62568	SCREW, (#10-16 x .375), WIRE A	3			
9	84	65999A	CABLE ASSEMBLY, (Black)	1			
10	10	69092	SCREW, (1.25), IGNITION PLATE	3			
11	13	26393	LOCKWASHER, (.312), IGNITION	3			
12	12	36042	WASHER, IGNITION PLATE SCRI	6			
13	12	67264	WASHER, (Rubber), IGNITION PL	6			
14	23	67268	BUSHING, IGNITION PLATE SCRI	3			
15	87	33386A	SWITCH ASSEMBLY	1			
16	10	38055	SCREW, (.190-32 X .62), MERCUF	1			
17	11	45076	NUT, (#10-32), MERCURY SWITC	1			
18	10	87926	SCREW, (#10-32 x .500), LEAD AT	1			
19	84	88439A	BATTERY CABLE, Positive	1			
19	84	88439A	BATTERY CABLE, Negative	1			
20	84	96220A12	HARNESS, ENGINE (USE W/O RI	1			
20	84	96220A	HARNESS, ENGINE (USE W/REC	1			
21	88	79091	FUSE, (20 Ampere)	1			
22	84	95084A	CABLE ASSEMBLY, FUSE	1			
23	54	47483	J CLIP	3			
24	54	816311	CABLE TIE, (8.00 Inches), HARNE	AF			
25	89	68258A	STARTER SOLENOID	1			
26	11	45076	NUT, (#10-32), SOLENOID TERMI	2			
27	13	53166	LOCKWASHER, (.312), SOLENOID	2			
28	11	68292	NUT, (.312-18), SOLENOID TERM	2			
29	10	31716	SCREW, (.250-20 x .62), SOLENOI	2			
30	13	26392	LOCKWASHER, (.250)	2			
31	84	65999A	CABLE ASSEMBLY, (Black), UPPE	1			
32	84	91865A	CABLE ASSEMBLY (3" - WHITE/B	1			
32	84	88528A	CABLE ASSEMBLY (6" - RED/WH	1			
33	86	19437	TERMINAL BLOCK	1			
34	10	38055	SCREW, (.190-32 X .62)	2			
35	12	89302	WASHER, (.203 x .406 x .040)	2			
36	11	45076	NUT, (#10-32)	2			
37		814422T	COVER, IGNITION PLATE	1			
38	10	88447	SCREW, (.190-32 x .1.62)	2			