



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		880194T 1	COVER ASSEMBLY	1		
2	25	840525	GROMMET	2		
3	25	20116	GROMMET	1		
4	25	855613	GROMMET	1	(175/200)	
5	25	882840	GROMMET	1	(150)	
6		828358 2	CRANK POSITION SENSOR	1		
7	10	40011107	SCREW	2		
8		821583 2	PIN	1		5
9		826115 1	CLAMP	1		
10	54	883080	J CLAMP	2		
11	10	817504	SCREW (1/4-20 x 1-1/2 IN.)	12		
12	54	55098	J CLAMP	1		
13	37	881865	DECAL-CAUTION-START IN GEAR	1		
14		880131T 2	AIR HANDLER ASSEMBLY	1	(See Breakdown on Air Handler Co	
-		883511T02	POWERHEAD	1	(150)	
-		883600T02	POWERHEAD	1	(175/200)	

.005 TO .020 CLEARANCE BETWEEN CAM AND ROLLER
 WITH THROTTLE LEVER HELD AGAINST STOP.

