



8678

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		880194T05	COVER ASSEMBLY	1		
2	25	840525	GROMMET	2		
3	25	20116	GROMMET	1		
4	25	855613	GROMMET	1	(200)	
5	25	882840	GROMMET	1	(150)	
6		828358	SENSOR	1		
7	10	40011107	SCREW, (M5 x 16)	2		
8		821583	PIN, Special	1		5
9		896552T01	AIR HANDLER ASSEMBLY	1		
10	54	883080	J CLIP	2		
11	10	817504	SCREW, (.250-20 x 1.500)	12		
12	54	55098	J CLIP	1		
13	37	881865	DECAL, Caution-Start in Gear	1	(Start In Gear)	
-		883511T04	POWERHEAD	1	(150)	
-		883600T04	POWERHEAD	1	(200)	