



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		19587	1 PLATE, MOUNTING	1		
2	10	30720	SCREW, VOLTAGE REGULATOR	4		
3	13	26992	LOCKWASHER	4		
4	23	19661	SPACER	4		
5		18736A15	VOLTAGE REGULATOR	1		
6		18717	SEAL	1		
7	89	96158	STARTER SOLENOID	2		
8	10	90192	SCREW, STARTER SOLENOID	3		
9	84	88807A 6	WIRE ASSEMBLY (3-1/2" - BLACK)	1		
10	11	56374	NUT, SOLENOID SCREW	3		
11	11	26419	NUT, SOLENOID TERMINAL (8-32)	4		
12	11	94330	NUT, SOLENOID TERMINAL (1/4-4)	4		
13	85	97861	INSULATOR, STARTER SOLENOID	2		
14	84	87379A14	WIRE ASSEMBLY (2-3/4" - RED)	1		
14	84	88807A 8	WIRE ASSEMBLY (3-1/2" - BLACK)	2		
15	84	88807A29	CABLE (9" - BLACK)	1		
16	54	90077	STA-STRAP	AR		5
17		43542	COVER, IGNITION COIL	2		
18	339	7370A13	IGNITION COIL	6		
19	10	90048	SCREW, IGNITION COIL COVER	8		
20	11	90078	NUT, COVER SCREW/GROUND	14		
21	84	813715A 9	CABLE, HIGH TENSION	1		
22	85	63709A 1	PROTECTOR, HIGH TENSION COIL	6		
23	33	14103568	SPARK PLUG	6		
24	11	45076	NUT, IGNITION COIL TERMINAL	12		
25	84	88807A13	GROUND WIRE (5-1/2" - BLACK)	6		
26	10	69022	SCREW, GROUNDING WIRE	2		
27	84	69739A 7	HARNES ASSEMBLY, COIL TO	1	(#2,4 AND 6)	
28		54676	RETAINER	2		
29		814423T	COVER, COIL PLATE	1	SERIAL (C239553 & ABOVE)	
30	10	814343	SCREW	4	SERIAL (C239553 & ABOVE)	