



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		15221A	CYLINDER HEAD	2	
2	27	41246	GASKET, CYLINDER HEAD	2	2
3	10	98534	SCREW, CYLINDER HEAD (2")	23	
4	10	13450	SCREW, CYLINDER HEAD (SPEC	1	
4	12	25909	WASHER, CYLINDER HEAD SCR	24	
5		75692	THERMOSTAT	2	
6	27	62386	GASKET, THERMOSTAT	2	2
7		90390A	COVER, THERMOSTAT	2	
8	10	35386	SCREW, THERMOSTAT COVER (4	
9	22	68727	FITTING, ELBOW - WATER HOSE	1	
10	32	77653	HOSE, WATER DISTRIBUTION	2	
11	22	68728	FITTING, THERMOSTAT COVER	1	
12	54	90077	STA-STRAP, WATER HOSES	AP	5
13		97465	TEMPERATURE SENDER (STAR)	1	
13		13536A	TEMPERATURE SENSOR (PORT)	1	
14		13715	RETAINER, SENSOR AND SENDI	2	
15	10	98257	SCREW, RETAINER	2	
16		13192	DETONATION SENSOR	1	
17	11	45076	NUT, DETONATION SENSOR	1	
18		14593A	ADAPTOR PLATE	1	
19	10	28668	SCREW, ADAPTOR PLATE	8	
20	27	14697	GASKET, ADAPTOR PLATE	1	2
21		75953	REED BLOCK	6	
22	34	75362A	REED ASSEMBLY	6	
23		96183	REED CLAMP	12	
24	10	14783	SCREW, REEDS TO REED BLOC	60	
25	10	21558	SCREW, REED BLOCK ATTACHM	6	
26	10	90197	SCREW, REED BLOCK ATTACHM	6	
27	27	16737	GASKET, ADAPTOR PLATE	1	2
-	27	14697A87	GASKET SET		