



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		74897	PIVOT, TRIGGER PLATE	1		
2		62459	BALL JOINT, TRIGGER PLATE	1		
3	11	45076	NUT, LINK ROD	1		
4		76035	LINK ROD, TRIGGER PLATE	1		
5	11	46438	NUT, BALL JOINT	1		
6		41094A	LEVER, SPARK ADVANCE	1		
7	10	64022	SCREW, SPARK ADVANCE LEV	1		
8	11	64015	NUT, SPARK ADVANCE STOP S	1		
9		26852	CAP, SPARK ADVANCE LEVER	1		
10	10	69560	SCREW, SPARK ADVANCE LEVE	1		
11	11	68219	NUT, SPARK ADVANCE LEVER S	1		
12		48039	CAP, SPARK ADVANCE LEVER S	1		
13		41095T	LEVER, THROTTLE CONTROL	1		
14	10	55337	SCREW, THROTTLE LEVER/ADV	1		
15	23	55164	BUSHING, THROTTLE LEVER	1		
16	23	55171	BUSHING, SPARK ADVANCE LEV	1		
17	24	68784	SPRING, THROTTLE AND SPARK	1		
18	12	68410	WASHER, SPARK ADVANCE LEV	1		
19	10	64022	SCREW, THROTTLE LEVER - STI	1		
20	11	64015	NUT, THROTTLE LEVER STOP S	1		
21		26852	CAP, THROTTLE LEVER STOP SI	1		
22		39483	LATCH, CABLE	1		
23	10	22486	SCREW, CABLE LATCH TO THRC	1		
24	24	20099	SPRING, CABLE LATCH TO THRC	1		
25	11	20586	NUT, CABLE LATCH SCREW	1		
26		95829	ROD, THROTTLE CONTROL	1		
27		60572	BARREL, THROTTLE CONTROL I	2		
28		95791	THROTTLE CAM	1		
29	16	20353	STUD, THROTTLE CAM ATTACH	1		
30	23	26856	BUSHING, THROTTLE CAM	2		
31	11	35045	NUT, THROTTLE CAM STUD	1		
32	24	41050	SPRING, THOTTLE RETURN	1		
33		92032A	BRACKET, ANCHOR - CTRL CABL	1	SERIAL (00239552 & BELOW)	
33		814283A	BRACKET, ANCHOR	1	SERIAL (00239553 & ABOVE)	
34		98889	LATCH, CONTROL CABLE	1		
35	10	42975	SCREW, LATCH	2		
36		39519	CAP, BARREL RETAINER - ANCH	1		
37	23	26600	BUSHING, NYLON - LINK ROD	1		
38	12	35462	WASHER, LINK ROD	1		
39	11	35045	NUT, LINK ROD TO SHIFT SHAF	1		
40	10	62167	SCREW, ANCHOR BRACKET ATT	2		