



19021

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		99659A21	MANIFOLD ASSEMBLY	1	(BLACK)	
1		99659A22	MANIFOLD ASSEMBLY	1	(GRAY)	
2	22	99616	PIPE PLUG, MANIFOLD	11		
3		41493A 7	TRIM CYLINDER ASSEMBLY	1	(BLACK)	
3		41493A 4	TRIM CYLINDER ASSEMBLY	1	(GRAY)	
4		41492A 1	GUIDE ASSEMBLY	1		
5	25	41478A 1	REPAIR KIT	1		
6		41482A 2	CHECK VALVE KIT	1		
7		99638A 1	GUIDE ASSEMBLY, TRIM ROD	2		
8		43397A 6	PISTON AND ROD ASSEMBLY, P	1		
9	35	12184A 1	TRIM FILTER ASSEMBLY	1		
10		43398A 3	PISTON AND ROD ASSEMBLY, S	1		
11	17	13794	PIN, Groove, TRIM CYLINDER (UF	1		
12		812843A 1	VALVE ASSEMBLY	1		
12A	53	812844	E RING	1		
13	10	40003 27	SCREW, (M6 x 14), COVER	4		
14	12	43450	WASHER, COVER SCREW	4		
15		99642	COVER, MANIFOLD	1		
16	25	48462A 2	O-RING KIT	1		
17	19	99609A 1	PLUG ASSEMBLY	1		
18		99641A 1	SHAFT ASSEMBLY	1		
19	22	99616	PIPE PLUG, SHAFT	2		
20	10	40088 20	SCREW, (M6 x 20), PUMP AND MI	2		
21	13	40025 6	LOCKWASHER, (M6)	2		
22		99186T	PUMP AND MOTOR	1		
23		99625	SHAFT, UPPER	1		
24		43396A 2	ANODE ASSEMBLY	1		
25	10	40003 30	SCREW, (M6 x 25), ANODE	2		
26	12	29245	WASHER, (.281 x .500 x .060), A	2		
27		99630 1	STRIKER PLATE, TRIM SHAFT	2		
28	13	58643	LOCKWASHER, (.375)	2		
29	11	46335	NUT, (.375-24)	2		
30	84	99695A 1	CONTROL HARNESS ASSEMBLY	1	(3 WIRE)	
30	84	17201A 1	CONTROL HARNESS ASSEMBLY	1	(2 WIRE)	
31	84	79138A12	WIRE ASSEMBLY	1	(13-1/4" - BLACK)	
31	84	88807A 8	WIRE ASSEMBLY, (Black- 3.5 Incl	2	(3-1/2" - BLACK)	
31	84	87379A14	WIRE ASSEMBLY, (2.750 Inches)	1	(RED)	
32	89	96158	SOLENOID STARTER	2		
33	10	28635	SCREW, (.250-20 x .620)	3		
34	11	26419	NUT, (#8-32)	4		
35	12	26982	LOCKWASHER, (.250)	4		