



12020

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1647	9148A11	GEAR HOUSING ASSEMBLY, Bas	1	(Design I With Out Anodes)	
1	1647	9148A12	GEAR HOUSING ASSEMBLY, Bas	1	(Design I With Out Anodes)	
1	1647	9148A47	GEAR HOUSING, Basic Gray	1	(Design II With Anodes)	
1	1647	9148A48	GEAR HOUSING, Basic Gray	1	(Design II With Anodes)	
47		78956	SHIFT CAM	1		
48		89594A	FOLLOWER	1		
49		79911	ROD	1		
50	24	79910	SPRING	2		
51	12	78910	WASHER	AR		5
52	17	78906	PIN	1		
53		14469	BEARING CUP	1		
54	30	88957A	BEARING	1		
55		N.S.S.	Not Sold Seperate, Reverse Gear (I	1		
56	31	15844	BEARING ASSEMBLY, Roller	1		
57	17	78909	PIN, Detent	2		
58	52	823174	CLUTCH	1		
59	17	78905	PIN, Cross	1		
60	24	78962	SPRING	2		
61	43	18475A	FORWARD GEAR	1		
62	23	17615	1 SPACER SHIM	AR		5
62	23	17615	2 SPACER SHIM	AR		5
62	23	17615	3 SPACER SHIM	AR		5
62	23	17615	4 SPACER SHIM	AR		5
62	23	17615	5 SPACER SHIM	AR		5
62	23	17615	6 SPACER SHIM	AR		5
62	23	17615	7 SPACER SHIM	AR		5
62	23	17615	8 SPACER SHIM	AR		5
62	23	17615	9 SPACER SHIM	AR		5
62	23	17615	10 SPACER SHIM	AR		5
62	23	17615	11 SPACER SHIM	AR		5
62	23	17615	12 SPACER SHIM	AR		5
62	23	17615	13 SPACER SHIM	AR		5
63	31	15841	ROLLER BEARING	1		
64	12	17616	THRUST RING	1		
65	25	31534	O-RING	1		2.8
66		18447A	2 BEARING ADAPTOR	1		
67	31	15843	ROLLER BEARING	1		
68	12	18448	THRUST WASHER	2		
69	31	15842	BEARING, Thrust	2		
70	44	18446	PROPELLER SHAFT	1		
71		91899CA	BEARING CARRIER	1		