



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		79918A 1	COVER ASSEMBLY, FLYWHEEL	1		
2		79022	MARKER, TIMING	1		
3	10	37572	SCREW TIMING MARKER	2		
4	12	72761	WASHER, TIMING MARKER SC	2		
5	19	89219	PLUG, FLYWHEEL COVER	1		
6	19	45907	PLUG, FLYWHEEL	1		
7	11	52901	NUT, FLYWHEEL	1		
8	12	68229	WASHER, FLYWHEEL	1		
9	257	7555A17	FLYWHEEL	1		
10	10	32417	SCREW, FLYWHEEL PLATE	8		
11	10	68997	SCREW, FLYWHEEL HUB	8		
12	398	5454A35	STATOR	1		
13	10	76566	SCREW, STATOR (1")	4		
14	84	69739A 3	HARNASS ASSEMBLY, COIL TO E	1	(#2, 4 AND 6)	
15		96455A11	TRIGGER PLATE ASSEMBLY	1		
16	50	79472	STARTER MOTOR	1		
17		56703	COLLAR, STARTER MOTOR	2		
18		68042	STOP, RUBBER - STARTER MOT	2		
19	13	26992	LOCKWASHER, STARTER MOTO	1		
20	11	20890	NUT, STARTER MOTOR TERMIN	1		
21	84	93388A 2	WIRE, SOLENOID TO STARTER M	1		
22	10	69035	SCREW, CABLE TO STARTER M	1		
23	84	93388A 1	WIRE, PLATE TO STARTER MOT	1		
24	339	7370A13	COIL ASSEMBLY, IGNITION	6		
25		67614	COVER, IGNITION COIL	3		
26	10	88447	SCREW, IGNITION COIL COVER	12		
27	12	30164	WASHER, COIL COVER SCREW	12		
28	11	45076	NUT, IGNITION COIL TERMINAL	12		
29	84	88807A 6	GROUND STRAP, IGNITION COIL	6		
30	10	68513	SCREW, GROUND STRAP	6		
31	84	99215A25	CABLE, HIGH TENSION	6		
32	85	63709A 1	PROTECTOR, HIGH TENSION C	6		
33	33	13686 2	SPARK PLUG	6		
33	33	14103568	SPARK PLUG (CANADA/BELGIUM)	6		