



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		67245	BRACKET, COWL MOUNTING - U	1		
2	25	67272	GROMMET, COWL MOUNTING B	2		
3		90435	MOUNT, COWL MOUNTING BRAI	2		
4	12	21249	WASHER, MOUNT ATTACHING	2		
5	11	20361	NUT, MOUNT ATTACHING	4		
6		90552A 2	HIGH SPEED CONTROL ASSEMB	1		
7	27	89221	GASKET, SOUND ATTENUATOR	3		6
8		88509	PLATE, SOUND ATTENUATOR	1		
9		87659	INLET, SOUND ATTENUATOR	2		
10	10	48408	SCREW, INLET TO SOUND ATTE	6		
11	27	87736	GASKET, COVER	1		6
12		93518A 1	COVER, SOUND ATTENUATOR	1		
13	10	48408	SCREW, COVER TO SOUND ATT	9		
14	10	88488	SCREW, SOUND ATTENUATOR I	4		
15	10	88489	SCREW, SOUND ATTENUATOR I	2		
16	12	35462	WASHER, SOUND ATTENUATOR	6	USED ON EARLY STYLE ENGIN	
17	25	89079	GROMMET, SOUND ATTENUATC	6	USED ON EARLY STYLE ENGIN	
18		90365	VALVE, ENRICHER	1		
19	22	90275	CONNECTOR, ENRICHER VALVE	1		
20	22	89097	CONNECTOR, ENRICHER VALVE	1		
21		90345	BRACKET, ENRICHER VALVE	1		
22	10	89075	SCREW, VALVE TO BRACKET	2		
23	10	28688	SCREW, BRACKET TO REED BLC	2		
24		45915	TERMINAL BLOCK, REED BLOCK	1		
25	10	69079	SCREW, TERMINAL BLOCK ATT/	1		
26	10	69079	SCREW, WIRE TO TERMINAL BL	1		
27	32	54935 79	FUEL LINE, MIDDLE CARBURETC	1		
28	32	52742A 1	FUEL LINE	2	VALVE TO CARBURETOR TO C/	
-	27	89221A80	GASKET SET			