



| Parts List | | | | | | |
|------------|-------|----------|-----------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 76258A 2 | BRACKET, REAR COWL (BLACK) | 1 | | |
| 1 | | 76258A 3 | BRACKET, REAR COWL (GRAY) | 1 | | |
| 2 | 22 | 76256 | NOZZLE, TELL TALE | 1 | | |
| 3 | | 67984 | SEAL, REAR COWL BRACKET TC | 1 | | |
| 4 | | 67228 | SEAL, REAR COWL BRACKET TC | 1 | | |
| 5 | | 67999 | SEAL, REAR COWL BRACKET TC | 2 | | |
| 6 | 32 | 99127109 | HOSE, TELL TALE (4") | 2 | | |
| 7 | 22 | 90824 | TEE, TELL TALE HOSE | 1 | | |
| 8 | | 73498 | STA-STRAP, TELL TALE HOSE | AR | | 5 |
| 9 | | 86386A 1 | BRACKET ASSEMBLY, COWL SU | 1 | | |
| 10 | 10 | 66687 | SCREW, REAR COWL BRACKET | 4 | | |
| 11 | | 85651 | HOUSING, COWL HINGE - PORT | 2 | | |
| 11 | | 85650 | HOUSING, COWL HINGE - STARE | 2 | | |
| 12 | 10 | 64278 | SCREW, COWL HINGE HOUSING | 8 | | |
| 13 | 12 | 20583 | WASHER, COWL HINGE HOUSING | 8 | | |
| 14 | 11 | 35888 | NUT, COWL HINGE HOUSING SC | 8 | | |
| 15 | | 90435 | MOUNT, COWL MOUNTING BRAC | 3 | | |
| 16 | 12 | 29245 | WASHER, COWL MOUNTING BR | 6 | | |
| 17 | 11 | 35888 | NUT, COWL MOUNTING BRACKE | 6 | | |
| 18 | | 99424 | BRACKET, COWLING MOUNTING | 1 | | |
| 19 | | 99447T | RETAINER, CABLE | 1 | | |
| 20 | 10 | 22411 | SCREW, CABLE RETAINER (1") | 2 | | |
| 21 | | 67260 | SEAL, CONTROL CABLES | 1 | | |
| 22 | | 67241 | HOUSING, COWL LATCH | 1 | | |
| 23 | 10 | 92051 | SCREW, COWL LATCH HOUSING | 2 | | |
| 24 | | 87608 | COWL LATCH | 1 | | |
| 25 | 24 | 60295 | SPRING, COWL LATCH | 1 | | |
| 26 | | 88622 | PLATE, CABLE RETAINER | 1 | | |
| 27 | | 99391 | RETAINER, OIL LINES | 1 | | |
| 28 | 10 | 69093 | SCREW, LOWER BRACKET | 2 | | |
| 29 | 12 | 20346 | WASHER, LOWER BRACKET SCF | 4 | | |
| 30 | 12 | 57427 | WASHER, LOWER BRACKET SCF | 2 | | |
| 31 | 23 | 88180 | BUSHING, LOWER BRACKET GR | 2 | | |
| 32 | 25 | 88033 | GROMMET, LOWER BRACKET | 2 | | |
| 33 | | 13719T | PLATE, RETAINING | 1 | | |