



| Parts List | | | | | | |
|------------|-------|-----------|-------------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 43429 | PLATE, IGNITION | 1 | | |
| 2 | 332 | 7778A 6 | SWITCH BOX | 2 | | |
| 3 | 10 | 13669 | SCREW, SWITCH BOX TO IGNITI | 2 | | |
| 4 | 23 | 94453 | BUSHING, SWITCH BOX SCREW | 2 | | |
| 5 | 11 | 45076 | NUT, SWITCH BOX TERMINAL | 8 | | |
| 6 | 84 | 60871A10 | WIRE, SWITCH BOX | 2 | | |
| 7 | 12 | 62568 | SCREW, WIRE ATTACHING | 2 | | |
| 8 | 10 | 87926 | SCREW, CABLE TO IGNITION PL | 1 | | |
| 9 | 84 | 65999A 3 | CABLE ASSEMBLY, (BLACK) | 1 | | |
| 10 | 10 | 69092 | SCREW, IGNITION PLATE (1-1/4" | 3 | | |
| 11 | 13 | 26393 | LOCKWASHER, IGNITION PLATE | 3 | | |
| 12 | 12 | 36042 | WASHER, IGNITION PLATE SCRE | 6 | | |
| 13 | 12 | 67264 | WASHER, IGNITION PLATE SCRE | 6 | | |
| 14 | 23 | 67268 | BUSHING, IGNITION PLATE SCRI | 3 | | |
| 15 | | 62351A 1 | RECTIFIER | 1 | | |
| 16 | 10 | 38055 | SCREW, RECTIFIER TO IGNITION | 2 | | |
| 17 | 11 | 45076 | NUT, RECTIFIER TERMINALS | 3 | | |
| 18 | 87 | 33386A 3 | MERCURY SWITCH | 1 | | |
| 19 | 10 | 38055 | SCREW, MERCURY SWITCH TO | 1 | | |
| 20 | 11 | 45076 | NUT, MERCURY SWITCH TERMI | 1 | | |
| 21 | 10 | 42813 | SCREW, LEAD ATTACHING | 1 | | |
| 22 | 84 | 88439A14 | BATTERY CABLE, POSITIVE | 1 | | |
| 22 | 84 | 88439A 2 | BATTERY CABLE, NEGATIVE | 1 | | |
| 23 | 84 | 96220A 6 | HARNESS, ENGINE | 1 | | |
| 24 | 88 | 79091 | FUSE | 1 | | |
| 25 | | 73498 | STA-STRAP, HARNESS AND CAB | AR | | 5 |
| 26 | 89 | 15857 | STARTER SOLENOID | 1 | | |
| 27 | 10 | 31716 | SCREW, SOLENOID TO IGNITION | 2 | | |
| 28 | 13 | 26392 | LOCKWASHER, SOLENOID TO IC | 2 | | |
| 29 | 84 | 65999A 2 | CABLE ASSEMBLY, UPPER MOUI | 1 | | |
| 30 | 11 | 45076 | NUT, SOLENOID TERMINALS (10 | 2 | | |
| 31 | 13 | 53166 | LOCKWASHER, SOLENOID TERM | 2 | | |
| 32 | 11 | 68292 | NUT, SOLENOID TERMINALS (5/ | 2 | | |
| 33 | 85 | 97861 | INSULATOR, SOLENOID | 1 | | |
| 34 | 10 | 48409 | SCREW, VOLTAGE REGULATOR | 2 | | |
| 35 | 84 | 13397A 1 | HARNESS ASSEMBLY | 1 | | |
| 36 | 11 | 45076 | NUT, VOLTAGE REGULATOR | 2 | | |
| 37 | | 88825A 7 | VOLTAGE REGULATOR | 1 | | |
| 38 | | 45915 | TERMINAL BLOCK | 2 | | |
| 39 | 10 | 48408 | SCREW, TERMINAL BLOCK | 4 | | |
| 40 | 84 | 88825A 20 | CABLE ASSEMBLY (RED) | 1 | | |