



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1647	7350A26	GEAR HOUSING ASSY,COMP.(LC)	1		
-	1647	7350A27	GEAR HOUSING ASSY,COMP.(EX)	1		
1	1647	7350A 4	GEAR HOUSING ASSY	1	SEE "TRANSOM BRACKETS" FC	
49/E		89594A 1	CAM FOLLOWER	1		
51		79911	ROD,CLUTCH ACTUATOR	1		
52	24	79910	SPRING, COMPRESSION	2		
53	12	78910	WASHER,COMPRESSION SPRING	AR		3
54	17	78906	PIN, SPRING LOCATOR	1		
55	15	47397A 1	SHIM, BEARING OUTER RACE	AR		3
56	31	78172A 1	TAPERED ROLLER BEARING A	1		
57	31	73363	ROLLER BEARING, FORWARD	2		
58	43	77673A 3	FORWARD GEAR	1		
59	52	78959	RATCHET, SLIDING CLUTCH	1		
60	17	78905	CROSS PIN,RATCHET TO PROI	1		
61	17	78909	DETENT PIN, RATCHET	2		
62	24	78962	SPRING, RETAINING-CROSS PI	2		
63	44	94148	PROPELLER SHAFT	1		
64	43	78908	REVERSE GEAR	1		
65		68100	THRUST RING	1	BEARING CARRIER TO GEAR H	
66	30	35914	BALL BEARING, REVERSE GEA	1		
67	25	31534	"O"RING, BEARING CARRIER	1		6
68		96184A 1	BEARING CARRIER ASSEMBLY	1		
69	31	30956	ROLLER BEARING, BEARING	1		
70	26	76868	OIL SEAL, BEARING CARRIEF	1		
70A	26	70081	OIL SEAL, BEARING CARRIEF	1		
71	28	30281	KEY,LOCATING-BEARING CARF	1		
72	14	79447	TAB WASHER, GEAR HOUSING	1		
73		79448	COVER, GEAR HOUSING	1		
74		31640A 1	TRIM TAB, GEAR HOUSING	1		
75	10	66024	SCREW,TRIM TAB TO GEAR HI	1		
76	12	45176	WASHER, DRIVE SHAFT HOUSIN	2		
77	11	34933	NUT,DRIVE SHAFT HOUSING ST	2		
78	10	65210	SCREW, GEAR HOUSING (LONG	1		
78	10	74727	SCREW, GEAR HOUSING (EXTRA	1		
79		77987	THRUST HUB	1		
80	12	31211	WASHER,SPLINED-PROPELLER	1		
81	14	31210	TAB WASHER, PROPELLER NUT	1		
82	11	52707	PROPELLER NUT	1		
-	27	89221A80	GASKET SET			