



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		91951	BRACKET, ANCHOR - CONTROL	1	
2	10	53167	SCREW, ANCHOR BRACKET	3	
3		67073A 1	LINK ROD ASSEMBLY	1	
4	24	20099	SPRING, LINK ROD TO GUIDE BL	1	
5		37896	GUIDE BLOCK, LINK ROD	1	
6		52100	WEAR PLATE, LINK ROD	1	
7		38279	LATCH, CONTROL CABLE FASTE	1	
8	12	21631	WASHER, LATCH	1	
9	11	20586	NUT, LINK ROD	1	
10		79932A 7	SHIFT SHAFT ASSEMBLY (LONG)	1	
10		79932A 8	SHIFT SHAFT ASSEMBLY (EXTRA	1	
12	13	29720	WAVE WASHER, LINK ROD	1	
13	23	26600	BUSHING, NYLON - LINK ROD	1	
14	12	24664	WASHER, LINK ROD	1	
15	11	20586	NUT, LINK ROD TO SHIFT SHAF	1	
16		39519	CAP, BARREL RETAINER - ANCH	1	
17		87609	LEVER, NYLON - SHIFT CABLE LI	1	
18	17	47175	PIN, LOCATING LEVER AND COV	3	
19		65799	LINK, LOCKING LEVER TO COVEI	1	
20		90211	COVER, NYLON - SHIFT CABLE	1	
21		89735	THROTTLE CAM (CASTING #897	OPT	4
21		95791	THROTTLE CAM (CASTING #957	OPT	4
21A	24	91821	SPRING, THROTTLE RETURN	1	
22	23	26600	BUSHING, THROTTLE CAM	2	
23	16	20353	STUD, THROTTLE CAM	1	
24	11	36069	NUT, THROTTLE CAM STUD	1	
25		60572	BARREL, THROTTLE CONTROL I	2	
26		95829	ROD, THROTTLE CONTROL	1	
27		90561	LEVER, THROTTLE CONTROL	1	
28	10	55337	SCREW, THROTTLE AND SPARK	1	
29	23	55164	BUSHING, THROTTLE LEVER	1	
30	23	55171	BUSHING, SPARK ADVANCE LEV	1	
31	24	68784	SPRING, THROTTLE AND SPARK	1	
32	12	68410	WASHER, SPARK ADVANCE LEV	1	
33		75154	LEVER, SPARK ADVANCE	1	
34	10	75168	SCREW, SPARK LEVER - STOP (1	
35	11	64484	NUT, SPARK ADVANCE LEVER S	1	
36	10	54467	SCREW, SPARK ADVANCE LEVE	1	
37	11	68219	NUT, SPARK ADVANCE LEVER S	1	
38		48039	CAP, SPARK ADVANCE LEVER S	1	
39		52022	CAP, SPARK ADVANCE LEVER S	1	