



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1494	7476	BRACKET, TRANSOM (PORT)	1		
2	10	67755	SCREW, BRACKET TO TRANSOM	2		
2	10	67757	SCREW, BRACKET TO TRANSOM	2		
3	12	28421	WASHER, BRACKET SCREW	4		
4	11	35000	NUT, BRACKET SCREW	4		
5	1495	7478	BRACKET, TRANSOM (STARBOARD)	1		
6	10	87180	BOLT, TILT	1		
7	11	20220	NUT, TILT BOLT	1		
8		79610A 6	TRIM CYLINDER ASSEMBLY	1		
9	23	86489	BUSHING, TRIM CYLINDER	2		
10	12	85022	WASHER, TRANSOM BRACKET	2		
11	24	30316	SPRING, TRIM CYLINDER	2		
12	17	85020	PIVOT PIN, TRIM CYLINDER	2		
13		85024	SHAFT, TRIM CYLINDER	1		
14	23	86637	BEARING, TRIM SHAFT	2		
15	17	91862	PIN, TRIM CYLINDER	1		
16		85026	PLATE, PIVOT PIN	2		
17	10	28636	SCREW, PLATE TO TRANSOM BRACKET	4		
18	12	29245	WASHER, PLATE SCREW	4		
19		85035	SPACER, TRANSOM BRACKET	1		
20	10	70732	SCREW, SPACER TO TRANSOM	4		
21	12	29245	WASHER, SPACER SCREW	4		
22		89949A 1	PLATE ASSEMBLY, TRANSOM BRACKET	1		
23	10	89996	SCREW, PLATE TO TRANSOM BRACKET	4		
24	32	85033	HOSE, HYDRAULIC - PORT	1		
25	32	85032	HOSE, HYDRAULIC - STARBOARD	1		
26	54	88512	CLAMP, HYDRAULIC HOSE	4		
27	10	88829	SCREW, CLAMP TO TRANSOM BRACKET	4		
28	13	26996	LOCKWASHER, CLAMP SCREW	4		
29		87871	COVER, INLET-HYDRAULIC HOSE	1		
30	27	87775	GASKET, INLET COVER	1		
31	10	32866	SCREW, INLET COVER	4		
32	12	20878	WASHER, INLET COVER SCREW	4		
33	11	29488	NUT, INLET COVER SCREW	4		
34	25	45507	GROMMET, INLET COVER	1		
35	22	87207	CONNECTOR, HYDRAULIC HOSE	1		