



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	467	7587A 2	CRANKSHAFT ASSEMBLY	1	
2	30	88268	BALL BEARING, CRANKSHAFT	1	
3	53	89531	RETAINING RING, BALL BEARII	1	
4		89938	SEAL, CRANKSHAFT/DRIVESHA	1	11
5		89939	SEAT, CRANKSHAFT/DRIVESHA	1	
6		88261	RING, SEALING - CRANKSHAFT	9	
7	31	88270	BEARING RACE, CENTER MAIN	2	
8	31	88269	ROLLER BEARING, CENTER MAI	1	
9	769	8179A 2	PISTON ASSEMBLY (STARBOARD)	3	
9	769	8180A 2	PISTON ASSEMBLY (PORT)	3	
10	39	88256A12	PISTON RING ASSEMBLY	1	
11	53	88466	LOCK RING, PISTON	12	
12	631	8185A 3	CONNECTING ROD ASSEMBLY	6	
13	10	94320	SCREW, CONNECTING ROD (3, AR		3
13	10	96114	SCREW, CONNECTING ROD (5, AR		3
14	31	88259A 1	ROLLER BEARING ASSEMBLY,	6	
15	12	88263	WASHER, NEEDLE LOCATING	12	
16	29	88258	NEEDLE BEARING, PISTON EN	204	
17	28	91800	KEY, CRANKSHAFT	1	
18		88266A 3	CARRIER ASSEMBLY	1	
19	31	88267	ROLLER BEARING	1	
20	26	41953	OIL SEAL	1	
21	25	64067	"O"RING	1	11
22	12	68229	WASHER, FLYWHEEL NUT	1	
23	11	52901	NUT, FLYWHEEL	1	
--	27	88605A80	GASKET SET	--	CONTENTS INDICATED BY FOO