



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1494	7476	1 BRACKET, TRANSOM (PORT)	1		
2	1495	7478	1 BRACKET, TRANSOM (STARBOARD)	1		
3	10	67755	2 SCREW, BRACKET TO TRANSOM	2		
4	10	67755	1 SCREW, BRACKET TO TRANSOM	2		
5	12	28421	4 WASHER, BRACKET SCREW	4		
6	11	91962	4 NUT, BRACKET SCREW	4		
7	10	87180	1 BOLT, TILT	1		
8	11	20220	1 NUT, TILT BOLT	1		
9		99170A	1 TILT TUBE	1		
10	12	85022	2 WASHER, TILT TUBE	2		
11	11	56041	1 NUT, TILT TUBE (7/8-14)	1		
11	11	34862	1 NUT, TILT TUBE (1"-14)	1		
12	25	45711	1 "O"RING, TILT TUBE	1		
13		85026	2 PLATE, PIVOT PIN	2		
14	10	28636	4 SCREW, PLATE TO TRANSOM BRACKET	4		
15	12	29245	4 WASHER, PLATE SCREW	4		
16		85035	1 SPACER, TRANSOM BRACKET	1		
17	10	70732	4 SCREW, SPACER TO TRANSOM BRACKET	4		
18	12	29245	4 WASHER, SPACER SCREW	4		
19		89949A	1 PLATE ASSEMBLY, TRANSOM BRACKET	1		
20	10	89996	4 SCREW, PLATE TO TRANSOM BRACKET	4		
21	54	88512	4 CLAMP, HYDRAULIC HOSE	4		
21	54	75275	2 CLAMP, WIRING HARNESS	2		
22	10	88829	6 SCREW, CLAMP TO TRANSOM BRACKET	6		
24		79610A	1 TRIM CYLINDER ASSEMBLY (79610A)	1		
25	23	86489	2 BUSHING, TRIM CYLINDER	2		
26	12	85022	2 WASHER, TRANSOM BRACKET	2		
27	24	30316	2 SPRING, TRIM CYLINDER	2		
28	17	85020	2 PIVOT PIN, TRIM CYLINDER	2		
29		85024	1 SHAFT, TRIM CYLINDER	1		
30	23	86637	2 BEARING, TRIM SHAFT	2		
31	17	91862	1 PIN, TRIM CYLINDER	1		
32	32	89024A	1 HOSE, HYDRAULIC (PORT)	1		
32	32	89023A	1 HOSE, HYDRAULIC (STARBOARD)	1		
33	25	97000	2 GROMMET, HYDRAULIC HOSE	2		
34	22	87207	1 CONNECTOR, HYDRAULIC HOSE	1		
35		87871	1 COVER, INLET - HYDRAULIC HOSE	1		
36	27	87775	1 GASKET, INLET COVER	1		
37	25	45507	1 GROMMET, INLET COVER	1		
38	10	36070	4 SCREW, INLET COVER	4		
39	12	26985	4 LOCK WASHER, INLET COVER SCREW	4		