



EXHAUST PLATE

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		43769	EXHAUST PLATE	1		
2	25	64872	GROMMET, POPPET VALVE	2		
3		65848	CARRIER, POPPET VALVE	2		
4		86596	POPPET VALVE	1		
5	24	90392	SPRING, POPPET VALVE	1		
6	27	88907	GASKET, RELIEF VALVE PLATE	2		11
7		65664A	1 PLATE, RELIEF VALVE	1		
8		64877	DIAPHRAGM	1		
9	12	76451	WASHER, DIAPHRAGM SCREW	1		
10	10	69570	SCREW, DIAPHRAGM TO PLATE	1		
11		65663A	1 COVER, RELIEF VALVE	1		
12	10	40001137	SCREW, COVER TO EXHAUST PI	4		
13	22	68727	ELBOW, EXHAUST PLATE	2		
14	17	20033	DOWEL PIN, LOCATING - EXHAU	2		
15	10	40062177	SCREW, EXHAUST PLATE (65 MP	1		
16	27	43877	GASKET, EXHAUST PLATE - UPF	1		11
17		88355	SEAL, EXHAUST PLATE TO COW	1		
18	27	43878	GASKET, EXHAUST PLATE - LOW	1		11
19		88880	1 PLATE, EXHAUST TUBE	1		
20	27	89084	GASKET EXHAUST TUBE	1		11
21	10	40001137	SCREW, PLATE TO DRIVE SHAF	3		
22	13	40024	7 LOCKWASHER, PLATE SCREW	3		
23		96843	1 SHIFT SHAFT, UPPER (LONG)	1		
23		96843	2 SHIFT SHAFT, UPPER (EXTRA LC	1		
24	23	27132	BUSHING, UPPER SHIFT SHAFT	1		
25		96841	LEVER, UPPER SHIFT SHAFT	1		
26	17	96888	ROLL PIN, LEVER TO SHIFT SHA	1		
27		96848	SHIFT LINK	1		
28	23	26856	BUSHING, SHIFT LINK	1		
29	13	29720	WAVEWASHER, SHIFT LINK	1		
30	11	36069	NUT, SHIFT LINK	1		
31	10	96849	SCREW, SHIFT LINK	1		
32	11	28770	NUT, SHIFT LINK SCREW (5/16-2	1		
33	13	29720	WAVEWASHER, SHIFT LINK SCF	2		
34	11	36069	NUT, SHIFT LINK SCREW (1/4-2E	1		
--	27	88605480	GASKET SET		CONTENTS INDICATED BY FOO	