



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		88364	BRACKET, COWL SUPPORT	1		
2		85651	HOUSING, COWL HINGE (PORT)	2		
2		85650	HOUSING, COWL HINGE (STARB)	2		
3	10	76621	SCREW, COWL HINGE HOUSING	8		
4	12	20583	WASHER, HOUSING SCREW	8		
5		88361	BRACKET, REAR COWL	1		
6		88358	SEAL, REAR COWL BRACKET	2		
7		88356	SEAL, REAR COWL BRACKET	1		
8	10	40003 35	SCREW, REAR COWL BRACKET	4		
9	12	40023 15	WASHER, REAR COWL BRACKET	4		
10		96209	PLATE, SOUND ATTENUATOR	1		
11		67245	BRACKET, COWL MOUNTING (UF)	1		
12	25	67272	GROMMET, COWL MOUNTING B	2		
13		90435	MOUNT	2		
14	12	21249	WASHER, MOUNT	4		
15	11	20361	NUT, MOUNT	4		
16	27	89819	GASKET, PLATE	1		11
17		88503	COVER, SOUND ATTENUATOR	1		
18	10	40062128	SCREW, COVER	14		
19		96854	BRACKET, COWL SUPPORT - FR	1		
20	25	67272	GROMMET, FRONT BRACKET	2		
21		88621	RETAINER, CABLE	1		
22	10	34994	SCREW, RETAINER TO FRONT E	2		
23		88357	SEAL, FRONT BRACKET	1		
24		88352	BOOT, FUEL ADAPTOR	1		
25	54	26550	CLIP, FRONT BRACKET	1		
26	10	78291	SCREW, CLIP	1		
27		69205	"C" WASHER, CLIP SCREW	1		
28		67241	HOUSING, COWL LATCH	1		
29	10	92051	SCREW, HOUSING TO FRONT B	2		
30		76264	COWL LATCH	1		
31	24	85367	SPRING, COWL LATCH	1		
32		90435	MOUNT	3		
33	12	21249	WASHER, MOUNT	6		
34	11	20361	NUT, MOUNT	6		
--	27	88605480	GASKET SET	--	CONTENTS INDICATED BY FOO	