



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		18896A 1	COVER KIT, Flywheel	1		
2		79022	MARKER, Timing	1		
3	10	37572	SCREW, (.190-32 x .380), Timing	2		
4	12	72761	WASHER, Timing Marker Screw	2		
5	19	89219	PLUG, Flywheel Cover	1		
6	19	45907	PLUG, (Yellow), Flywheel	1		
7	11	52901	NUT, (.625-18), Flywheel	1		
8	12	68229	WASHER, Flywheel	1		
9	266	9841A 2	FLYWHEEL	1		
10	10	32417	SCREW, (.250-28 x .625), Flywhe	8		
11	10	68997	SCREW, (.3125-24 X .75), Flywhe	8		
12	398	9610A 5	STATOR	1		
13	10	90045	SCREW, (#10-32 x 1.375), Stator	4		
14	13	26996	LOCKWASHER, (#10), Stator Scre	4		
15		96455A 9	TRIGGER PLATE ASSEMBLY	1		
16	84	93388A 1	CABLE ASSEMBLY, Black, Plate to	1		
17	50	79472	STARTER MOTOR	1		
18		56703	COLLAR, Starter Motor	2		
19		68042	STOP, Rubber-Starter Motor	2		
20	13	26992	LOCKWASHER, (.250), Starter Mot	1		
21	11	20890	NUT, (.250-20), Starter Motor Termi	1		
22	84	93388A 2	WIRE, (Black), Solenoid to Starter t	1		
23	10	69035	SCREW AND LOCKWASHER, (.25	1		