



18497

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		74897	PIVOT, TRIGGER PLATE	1		
2		62459	BALL JOINT ASSEMBLY, TRIGGE	1		
3	11	45076	NUT, (#10-32), LINK ROD	1		
4		76035	ROD, TRIGGER PLATE	1		
5	11	46438	NUT, (#10-32), BALL JOINT	1		
6		41094A 3	LEVER ASSEMBLY, SPARK ADVA	1		
7	10	64022	SCREW, (.250-20 x 2.125)	1		
8	11	64015	NUT, (.250-20)	1		
9		26852	CAP	1		
10	10	69560	SCREW, (.190-32 X 1.25), SPARK	1		
11	11	68219	NUT, (#10-32), SPARK ADVANCE	1		
12		48039	CAP	1		
13		41095T	LEVER, THROTTLE CONTROL	1		
14	10	55337	SCREW, (.375-16 x 1.75)	1		
15	23	55164	BUSHING, THROTTLE LEVER	1		
16	23	55171	BUSHING	1		
17	24	68784	SPRING	1		
18	12	68410	WASHER	1		
19	10	64022	SCREW, (.250-20 x 2.125)	1		
20	11	64015	NUT, (.250-20)	1		
21		26852	CAP	1		
22		39483	LATCH, CABLE	1		
23	10	22486	SCREW, (.250-28 x .88)	1		
24	24	20099	SPRING	1		
25	11	20586	NUT, (.250-28)	1		
26		79949	ROD, THROTTLE CONTROL	1		
27		60572	BARREL	2		
28		17886 1	THROTTLE CAM	1		
29	16	20353	STUD, (.250-28 x 1.750), THROTT	1		
30	23	26856	BUSHING, THROTTLE CAM	2		
31	11	36069	NUT, THROTTLE CAM STUD	1		
32	24	41050	SPRING, THROTTLE RETURN	1		
33		92032A 2	BRACKET, ANCHOR-CONTROL C	1		
34		98889	LATCH, CONTROL CABLE	1		
35	10	42975	SCREW, Drive	2		
36	10	53167	SCREW, (.312-18 x .880)	3		
37		37896	GUIDE BLOCK, LINK ROD	1		
38	24	20099	SPRING	1		
39		67073A 1	LINK ROD ASSEMBLY	1		
40		52100	WEAR PLATE, LINK ROD	1		
41		28278	LATCH	1		