



18528

Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1655	9572A 3	GEAR HOUSING (LONG)(BLACK)	1	
-	1655	9572A 4	GEAR HOUSING (LONG)(GRAY)	1	
1	1655	9572A 1	GEAR HOUSING (BLACK)	1	
1	1655	9572A 2	GEAR HOUSING (GRAY)	1	
2	22	85822A 1	CONNECTOR ASSEMBLY, SP	1	
3	17	20033	PIN, Dowel, GEAR HOUSING I	2	
4	16	78638	STUD, (.438 x 3.12), GEAR HO	1	
5	16	57920	STUD, (.44 x 2.06), GEAR HOL	2	
6	16	56297	STUD, (.312 x 3.38), WATER F	1	
7	16	30667	STUD, (.250-20/.250-28 x 3.12	2	
8	31	32898	BEARING	1	
9	10	79953	SCREW, (.375-16 x .250), GREAS	1	
10	22	67892	SCREW, Magnetic, DRAIN	1	
11	45	15298	DRIVESHAFT, GREASE FILLER	1	
12		NSS	NOT SOLD SEPARATE, PINION		
13	12	20260	WASHER, GREASE FILLER ANI	2	15,18
14	11	35921	NUT, (.625-18)	1	
15	15	42637A 1	SHIM SET	AR	
16	31	36387A 1	BEARING, Roller	1	
17	11	42633	NUT, DRIVESHAFT BEARING	1	
18	46	42579A 3	WATER PUMP BASE ASSEMBL	1	18
19	27	42631	GASKET	1	2,15,18
20	25	90011	O-RING, (2.175 x .175)	1	2,15,18
20	25	38099	O-RING (2.109 I.D.)	1	2,15,18
21	26	89238	OIL SEAL	1	15,18
22	26	16977	OIL SEAL	1	15,18
23	27	85608	GASKET, LOWER	1	2,15,18
24	27	85609	GASKET, UPPER	1	2,15,18
25		32435	FACE PLATE	1	18
26	46	96148A 1	WATER PUMP BODY ASSEMBL	1	18
27		48752	INSERT, WATER PUMP BOD	1	18
28	26	38970	SEAL, RUBBER	1	2,15,18
29	47	89984	IMPELLER, WATER PUMP	1	18
30	28	56654	KEY, IMPELLER DRIVE	1	18
31	10	96411	SCREW, (#14-8 x 2.25)	1	
32	12	29245	WASHER, (.281 x .500 x .060)	2	
33	11	13438	NUT, (.250-28)	2	
34	12	36001	WASHER	1	
35	11	13436	NUT	1	
36	25	30271	RING, RUBBER	1	2,15,18
37	22	28804	SLEEVE GUIDE	1	18