


AD31L-A, AD31P-A, AD41L-A, AD41P-A, D41L-A, TAMD31L-A, TAMD31M-A, TAMD31P-A, TAMD31S-A, TAMD41H-A, TAMD41H-B, TAMD41P-A, TAMD41L-A, TAMD41M-A, TMD31L-A, TMD41L-A



AD31L-A, AD31P-A, AD41L-A, AD41P-A, D41L-A, TAMD31L-A, TAMD31M-A, TAMD31P-A, TAMD31S-A, TAMD41H-A, TAMD41H-B, TAMD41P-A, TAMD41L-A, TAMD41M-A, TMD31L-A, TMD41L-A

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	873226	1	Control unit	
2	(873227)	1	Trimmer	Digital, Obsolete part
3	872498	1	• Trimmer	
4	858643	1	• Front ring	
5	(873136)	1	Trimmer	Analog, Obsolete part
6		1	• Trimmer	
7	863945	1	• Lamp socket	
8	863946	1	• Bulb	Red
9	858643	1	• Front ring	