



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	(837819)	1	Instrument panel		24V, Obsolete part
2	(837519)	1	• Instrument plate		Obsolete part
3	(837775)	1	• Tachometer		Obsolete part
4	(837758)	1	• Thermometer		Obsolete part
5	(837756)	1	• Instrument		Obsolete part
6	(837730)	1	• Voltmeter		Obsolete part
7	824963	1	• Starter switch		
8	(831606)	2	• Key		State key code when ordering, Obsolete part
			Bulletin P-36-4-1	P-36-4-1-EN	Deleted Part No's for Keys
9	(831536)	1	• Nut		Obsolete part
10	(827769)	1	• Collar		Obsolete part
11	843684	2	• Button		
12	837533	2	• Rubber cap		
13	842918	1	• Rheostat		
14	843002	1	• Nut		
15	842921	1	• Knob		
16	819350	2	• Sleeve		
17	808175	6	• Lamp socket		
18	182059	6	• Bulb		
19	827766	2	• Lens		
20	837722	1	• Resistor		
21	837878	1	• Relay		
22	955126	1	• Cross recessed screw		
22A	(192557)	1	• Spring nut		Obsolete part
23	(837267)	1	• Timer relay		Obsolete part
24	(837859)	2	• Anchorage		Obsolete part
25	948210	X	• Cable tie		
26	944540	4	• Screw		
27	(837887)	1	• Cable trunk		Obsolete part
28	(837888)	1	• Cable trunk		Obsolete part
29		X	• cables and terminals	16870	