



D13B-E MH

| REF | PART NO. | QTY | DESCRIPTION | NOTES |
|-----|----------|-----|---------------------|-------------|
| 1 | 1140319 | 1 | Battery main switch | 150A |
| | 3987034 | 1 | Main switch | 300A |
| 2 | | 1 | • Switch | |
| 3 | 1140427 | 1 | • Cock handle | For 1140319 |
| | 8157766 | 1 | • Key | For 3987034 |
| 4 | 1140428 | 2 | • Washer | |
| 5 | 17602 | 4 | • Hexagon nut | |