




D4-180I-F, D4-225A-F, D4-225I-F, D4-260A-F, D4-260D-F, D4-260I-F, D4-300A-F, D4-300D-F, D4-300I-F



26793

D4-180I-F, D4-225A-F, D4-225I-F, D4-260A-F, D4-260D-F, D4-260I-F, D4-300A-F, D4-300D-F, D4-300I-F

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	21875631	1	Kit	AUTO
2	(21888395)	1	• Control unit	Obsolete part
3	21888965	1	• Power cable	
4	(22079532)	1	Gps receiver	Obsolete part, www.garmin.com (support)
5	21812194	1	• Cable	
6	21812195	1	• Connector	
7	(22079542)	1	• Mounting kit	Obsolete part, www.garmin.com (support)
8	3889758	1	Converter	