



10511

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	860276	1	Heat exchanger		
2	860119	1	· Cover		
2A	860127	3	· Sealing strip		
3	925027	1	· O-ring		
4	964106	1	· Gasket		
5	963567	1	· Screw		
6	192134	1	· Plug		
7	838929	1	· Zinc anod		
8	958227	1	· O-ring		
9	858754	1	· Anchorage		
9A	960629	1	· Plug		
9B	11994	1	· Gasket		
10	838729	1	Bracket		
11	838733	2	Support ring		
12	838728	1	Bracket		
13	965185	3	Flange screw		
14	838737	1	Tube		HEAT EXCHANGER-CIRCULATION PUMP.
15	968927	4	O-ring		
16	838798	1	Coolant pipe		HEAT EXCHANGER-THERMOSTAT HOUSING.
17	967645	1	Clamp		
18	946544	1	Flange screw		
19	845879	1	Cover		
20	192618	X	Hose		
21	953003	1	Stud	02B-2354	
					L = 130 MM
21	953007	1	Stud	02B-2354	
					L = 150 MM
22	941908	2	Spring washer		
23	971095	2	Nut		
24	838780	1	Coolant pipe		HEAT EXCHANGER-AFTER COOLER.. PRODUCT NO.868448,868439,868448
	860278	1	Coolant pipe		REVERSE GEAR-HEAT EXCHANGER.. PRODUCT NO.868189,868190,868191
25	943475	2	Hose clamp		L = 60 MM
26	944386	1	Hose		
27	944386	1	Hose		L = 335 MM. HEAT EXCHANGER-EXHAUST BEND.
28	943475	1	Hose clamp		
29	858889	1	Decal		REPLACED BY DECAL KIT 876234
	876234	1	Decal set		
30	860230	1	Air vent hose		TURBO-HEAT EXCHANGER-THERMOSTAT HOUSING
31	11994	2	Gasket		
32	969299	1	Hollow screw		