



REF	PART NO.	QTY	DESCRIPTION	NOTES
1	422582	1		
2		1	• TURBINE HOUSING	
3	422658	1	• Rotor unit	
4		1	• • BEARING HOUSING	
5		2	• • • GUIDE PIN	
6	422659	1	• • Turbine rotor	
7		2	• • PISTON RING	IK
8	422360	1	• • Lock ring	
9		1	• • PLATE	
10		1	• • SLEEVE	IK
11		2	• • BEARING BUSHING	IK
12	417727	4	• • Lock ring	IK
13	467026	2	• • Thrust ring	
14		1	• • THRUST BEARING	IK
15	422660	1	• • Spacer sleeve	
16	422662	1	• • Splash plate	
17	422661	1	• • Ring retainer	
18		2	• • PISTON RING	IK
19	420466	1	• • Cover	
20		1	• • O-RING	IK
21	420467	1	• • Lock ring	
22	422663	1	• • Compressor wheel	
23	1518784	1	• • Nut	(422669)
24		1	• • PLATE	
25		2	• • SCREW	
26	417378	1	• • Gasket	IK
27	417381	1	• • Gasket	IK
28		1	• HOUSING	
29	422668	1	• Rubber ring	IK
30	422666	1	• Clamp	
31	422667	1	• Clamp	
32	420473	1	• Nut	
33	417382	1	• Gasket	IK
36	273179	1	Repair kit	