



3128

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	823365	1	Instrument panel		32V, Obsolete part
2	820184	1	• Instrument panel		Obsolete part
3	819386	1	• Tachometer		
4	827148	1	• Thermometer		Obsolete part
5	827188	1	• Resistor		Obsolete part
6	819427	1	• Instrument		Obsolete part
7	837437	1	• Starter switch		
8	240321	2	• • Key		For cable area 6,5-10,5mm ² ., Marked S, Obsolete part
			Bulletin P-36-4-1	P-36-4-1-EN	Deleted Part No's for Keys
8	241383	2	• • Key		For cable area 6,5-10,5mm ² ., Marked E, Obsolete part
			Bulletin P-36-4-1	P-36-4-1-EN	Deleted Part No's for Keys
9	819079	2	• Pull switch		Obsolete part
10	843684	2	• Button		
11	820217	1	• Sign		Obsolete part
12	820218	1	• Sign		Obsolete part
13	819346	1	• Glass, red		Obsolete part
14	663093	1	• Sleeve		For cable area 10,5-16,0mm ² ., Obsolete part
15	819136	1	• Sign		Obsolete part
16	19923	3	• Bulb		
	819791	1	• Bulb		For cable area 10,5-16,0mm ² ., Obsolete part
17	808175	3	• Lamp socket		
	804617	1	• Lamp socket		For cable area 10,5-16,0mm ² ., Obsolete part
18	821768	1	• Attaching brace		Obsolete part
19	942662	1	• Terminal block		Obsolete part
20	804777	2	• Screw		Obsolete part
21	821042	1	• Sign		Obsolete part
22		X	• cable and cable terminals	14035	
23	948210	X	• • Cable tie		(827353)