



3128

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	Instrument panel		24V
2	820184	1	• Instrument panel		Obsolete part
3	817572	1	• Tachometer		
4	827149	1	• Thermometer		
6	813864	1	• Instrument		
7	837437	1	• Starter switch		
8	240321	2	• • Key		For cable area 6,5-10,5mm <sup>2</sup> ., Marked S, Obsolete part
			Bulletin P-36-4-1	P-36-4-1-EN	Deleted Part No's for Keys
8	241383	2	• • Key		For cable area 6,5-10,5mm <sup>2</sup> ., Marked E, Obsolete part
			Bulletin P-36-4-1	P-36-4-1-EN	Deleted Part No's for Keys
9	819079	2	• Pull switch		Obsolete part
10	843684	2	• Button		
11	820217	1	• Sign		Obsolete part
12	820218	1	• Sign		Obsolete part
13	819346	1	• Glass, red		Obsolete part
14	819350	1	• Sleeve		
15	819136	1	• Sign		Obsolete part
16	182059	4	• Bulb		
17	808175	4	• Lamp socket		
18	821768	1	• Attaching brace		Obsolete part
19	942662	1	• Terminal block		Obsolete part
20	804777	2	• Screw		Obsolete part
21	821042	1	• Sign		Obsolete part
22		X	• cable and cable terminals	14035	
23	948210	X	• • Cable tie		(827353)