



REF	PART NO.	QTY	DESCRIPTION	NOTES
1	833669	1	Starter motor	
	3803073	1	Starter motor, exch, exch	
		1	• HOUSING	
2		4	• POLE SHOE	
3	956130	4	• Cross recessed screw	OBSOLETE PART
4	833724	1	• Field winding	OBSOLETE PART
5	833725	1	• Bearing shield	OBSOLETE PART
6	238813	1	• • Bushing	OBSOLETE PART
7	833726	1	• Bearing	OBSOLETE PART
8	833739	1	• • Bushing	OBSOLETE PART
9	833727	1	• Engagement lever	
10	241674	1	• Screw	OBSOLETE PART
11	941906	1	• Spring washer	
12	955781	1	• Hexagon nut	(244116)
13	833730	1	• Starter pinion	OBSOLETE PART
14	240620	2	• • Bushing	
15	238819	1	• Stop ring	OBSOLETE PART
16	833729	1	• Rotor	OBSOLETE PART
17		1	• PLATE	
18	840525	1	• Carbon brush set	(833733), OBSOLETE PART
19	834519	4	• Spring	(241887), OBSOLETE PART
20	240601	1	• Bearing	OBSOLETE PART
21	240602	1	• • Bushing	
22	833734	2	• Screw	OBSOLETE PART
23	86287	2	• Washer	OBSOLETE PART
24	240606	1	• Cover	OBSOLETE PART
25	956059	2	• Cross recessed screw	(241292)
26	941904	2	• Spring washer	
27	833735	1	• Actuator solenoid	
28	240626	X	• • Adjusting washer	TH = 0.5mm, OBSOLETE PART
	240627	X	• • Adjusting washer	TH=1.0mm, OBSOLETE PART
29	243248	1	• • Cover	OBSOLETE PART
30		2	• •	
31	941905	2	• • Spring washer	
32	955224	1	• • Hexagon screw	
33	240499	1	• • Washer	OBSOLETE PART
34	955782	1	• Hexagon nut	
35	941907	1	• Spring washer	
36	833736	2	• Screw	OBSOLETE PART
37	241300	1	• Repair kit	
38		1	• INSULATOR	