



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	850057	1	Upper gear		OBSOLETE PART
2	850058	1	• Gear housing		OBSOLETE PART
3	961638	1	• Grooved pin		OBSOLETE PART
4	832189	1	• Support washer		OBSOLETE PART
5	850060	1	• Cover		OBSOLETE PART
6	804342	1	• • Screw		OBSOLETE PART
7	804344	1	• • Gasket		
8	832140	1	• • Washer		OBSOLETE PART
9	832127	1	• Gear set		OBSOLETE PART
10	181290	2	• Ball bearing		OBSOLETE PART
11	832920	1	• Bearing box		OBSOLETE PART
12	832128	X	• Intermediate ring		TH = 11,850 MM, OBSOLETE PART
	832129	X	• Intermediate ring		TH = 11,875 MM, OBSOLETE PART
	832130	X	• Intermediate ring		TH = 11,900 MM, OBSOLETE PART
	832131	X	• Intermediate ring		TH = 11,925 MM, OBSOLETE PART
	832132	X	• Intermediate ring		TH = 11,950 MM, OBSOLETE PART
	832133	X	• Intermediate ring		TH = 11,975 MM, OBSOLETE PART
	832134	X	• Intermediate ring		TH = 12,000 MM, OBSOLETE PART
		X	• Intermediate ring		TH = 12,025 MM
	851732	X	• Intermediate ring		TH = 12,050 MM, OBSOLETE PART
	851733	X	• Intermediate ring		TH = 12,075 MM, OBSOLETE PART
	851734	X	• Intermediate ring		TH = 12,100 MM, OBSOLETE PART
13	907025	1	• Lock washer		
14	832923	1	• Lock nut		OBSOLETE PART
15	832952	1	• Gasket		
16	832921	1	• Bearing cover		OBSOLETE PART
17	958856	1	• Sealing ring		
18	955995	1	• O-ring		
19	850205	1	• Stub axle		OBSOLETE PART
20	946292	1	• Hex. socket screw		OBSOLETE PART
21	850203	1	• Washer		OBSOLETE PART
22	925094	1	• O-ring		
23	804301	X	• Adjusting washer		TH = 0,05 MM
	804221	X	• Adjusting washer		TH = 0.10mm, OBSOLETE PART
	804394	X	• Adjusting washer		TH = 0.20mm, OBSOLETE PART
24	959224	5	• Hex. socket screw		L = 35 MM
	959222	1	• Hex. socket screw		L = 25 MM
25	941907	6	• Spring washer		
26	813949	1	• Bearing sleeve		OBSOLETE PART
27	951953	1	• Spring pin		
28	850336	1	• Anchorage		OBSOLETE PART
29	959194	4	• Hex. socket screw		OBSOLETE PART
30	181287	2	• Ball bearing		
31	850290	1	• Shaft		
32	850303	1	• Sliding sleeve		
33	914456	1	• Snap ring		
34	850987	1	• Shim		OBSOLETE PART
35	813970	1	• Spring		
36	181268	4	• Needle roller assemb		
37	813939	3	• Spacer ring		
38	850761	2	• Pin		
39	87655	X	• Shim		TH = 0.10mm
	191840	X	• Shim		TH=0,15mm
40	813941	X	• Spacer ring		TH=5.0mm
	813971	X	• Spacer ring		TH = 5,1 MM, OBSOLETE PART
	813972	X	• Spacer ring		TH = 5,2 MM, OBSOLETE PART
	813973	X	• Spacer ring		TH = 5,3 MM, OBSOLETE PART
	813974	X	• Spacer ring		TH = 5,4 MM, OBSOLETE PART
41	814030	2	• Lock ring		
42	959224	4	• Hex. socket screw		
43	948486	X	• Shim		TH = 0,05 MM, OBSOLETE PART
	948487	X	• Shim		TH = 0.10mm, OBSOLETE PART
	948488	X	• Shim		TH = 0.20mm, OBSOLETE PART

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
44	925257	2	• O-ring		
45	834021	1	• Lever		
46	955270	2	• Hexagon screw		
47	955948	2	• Toothed washer		
48	955781	2	• Hexagon nut		
49	804312	1	• Cube		
50	955892	1	• Washer		
51	907834	1	• Split pin		
52	839505	1	• Bearing housing		
53	897816	1	• Eccentric piston		
			Bulletin P-44-1-7	P-44-1-7-EN	Shift mechanism, eccentric piston
54	897711	1	• Screw		
55	814184	1	• Spring		
56	897871	X	• Shim		TH = 0.20mm
57	839646	1	• Dog		
58	942871	1	• Clevis pin		
59	951924	1	• Spring pin		
60	958838	1	• Sealing ring		(941866)
61	925093	1	• O-ring		
62	850350	1	• Cable attachment		OBSOLETE PART
63	21471054	1	• Bracket		
64	819068	1	• Washer		
65	955246	2	• Hexagon screw		
66	946577	2	• Lock nut		
66A	940090	2	• Washer		
67	941906	4	• Spring washer		
68	955272	4	• Hexagon screw		
69	850207	1	• Oil dipstick		
70	850209	1	• Tube		OBSOLETE PART
71	925054	1	• O-ring		
72	851314	1	• Bracket		(850332), OBSOLETE PART
73	960148	4	• Washer		
74	955318	4	• Hexagon screw		
75	952076	1	• Plug		
76	852230	1	Tap		SEE GROUP 4A
77	801197	1	• Hose attachment		
78	850759	1	Hose clamp		OBSOLETE PART