



4518

4519

REF	PART NO.	QTY	DESCRIPTION	NOTES
1		1		
2		1	• turbine housing	
3	(837076)	1	• Rotor	Obsolete part
4		1	• • bearing housing	
5	(422659)	1	• • • Turbine rotor	Obsolete part
6		4	• • • piston ring	
7	(467026)	2	• • • Thrust ring	Obsolete part
8	(422660)	1	• • • Spacer sleeve	Obsolete part
9		2	• • • bearing	
10	(422661)	1	• • • Ring retainer	Obsolete part
11	(417727)	4	• • • Lock ring	Obsolete part
12		1	• • • sleeve	
13		1	• • • thrust bearing	
14	(422662)	1	• • • Splash plate	Obsolete part
15	(420466)	1	• • • Cover	Obsolete part
16		1	• • • o-ring	
17	(420467)	1	• • • Lock ring	Obsolete part
18	(837079)	1	• • • Compressor wheel	Obsolete part
19	(1518784)	1	• • • Nut	(422669), Obsolete part
20	417378	1	• • • Gasket	
21	417381	1	• • • Gasket	
22		1	• • • turbin backplate	
23	(422360)	1	• • • Lock ring	Obsolete part
24		1	• housing	
25	(422667)	1	• Clamp	Obsolete part
26		1	•	(420473)
27	417382	1	• Gasket	
28	(961896)	7	• Plug	Obsolete part
29	(957188)	7	• Gasket	Obsolete part
30	955524	10	• Hexagon screw	
31	941907	10	• Spring washer	
32	955984	10	• O-ring	
35	837080	1	Repair kit	