



3128

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	Instrument panel		24V
2	(820184)	1	• Instrument panel		Obsolete part
3	817572	1	• Tachometer		
4	827149	1	• Thermometer		
6	813864	1	• Instrument		
7	837437	1	• Starter switch		
8	(240321)	2	• • Key		For cable area 6,5-10,5mm ² ., Marked S, Obsolete part
			Bulletin P-36-4-1	P-36-4-1-EN	Deleted Part No's for Keys
8	(241383)	2	• • Key		For cable area 6,5-10,5mm ² ., Marked E, Obsolete part
			Bulletin P-36-4-1	P-36-4-1-EN	Deleted Part No's for Keys
9	(819079)	2	• Pull switch		Obsolete part
10	843684	2	• Button		
11	(820217)	1	• Sign		Obsolete part
12	(820218)	1	• Sign		Obsolete part
13	(819346)	1	• Glass, red		Obsolete part
14	819350	1	• Sleeve		
15	(819136)	1	• Sign		Obsolete part
16	182059	4	• Bulb		
17	808175	4	• Lamp socket		
18	(821768)	1	• Attaching brace		Obsolete part
19	(942662)	1	• Terminal block		Obsolete part
20	(804777)	2	• Screw		Obsolete part
21	(821042)	1	• Sign		Obsolete part
22		X	• cable and cable terminals	14577	
23	948210	X	• • Cable tie		(827353)