



4708

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	843307	1	Alarm panel		24V
2	(843349)	1	• Panel		Obsolete part
3	(843351)	1	• Plate		Obsolete part
4		2	•		
5	956050	6	• Cross recessed screw		
6	(955944)	6	• Toothed washer		Obsolete part
7	955778	6	• Hexagon nut		
8	(304307)	6	• Fuse holder		Obsolete part
9	(191206)	6	• Cover		Obsolete part
10	(956064)	6	• Cross recessed screw		Obsolete part
11	941904	6	• Spring washer		
12	955779	6	• Hexagon nut		
13	(88578)	2	• Fuse box		Obsolete part
14	(842401)	28	• Diode		Obsolete part
15	956063	4	• Cross recessed screw		
16	941904	4	• Spring washer		
17	955779	4	• Hexagon nut		
18	1504951	19	• Relay		
19	946556	19	• Housing		
20	(956077)	3	• Cross recessed screw		Obsolete part
21	955780	3	• Hexagon nut		
22	941905	3	• Spring washer		
23	952629	1	• Clamp		
24	956094	1	• Cross recessed screw		
25	941906	1	• Spring washer		
26	955781	1	• Hexagon nut		
27	(948771)	4	• Cross recessed sunk		Obsolete part
28	963104	4	• Lock nut		
29	843684	2	• Button		
30	837533	2	• Rubber cap		
31	808175	8	• Lamp socket		
32	182059	8	• Bulb		
33	819350	8	• Sleeve		
34	827766	8	• Lens		
35	944540	4	• Screw		
36			• cable and cable terminals	14577	